

# SERVICE MANUAL

TECHNICAL INFORMATION  
FOR SERVICE PERSONNEL ONLY

## airHome 600

**ROOM AIR CONDITIONER**  
**SPLIT TYPE**  
**VJ SERIES**

### MODEL

RAK-VJ60PHAE  
RAK-VJ70PHAE

### CONTENTS

SPECIFICATIONS	Page 5
HOW TO USE	Page 7
CONSTRUCTION AND DIMENSIONAL DIAGRAM	Page 47
MAIN PARTS COMPONENT	Page 48
WIRING DIAGRAM	Page 49
PRINTED WIRING BOARD LOCATION DIAGRAM	Page 51
CIRCUIT DIAGRAM	Page 53
BLOCK DIAGRAM	Page 55
BASIC MODE	Page 57
REFRIGERATING CYCLE DIAGRAM	Page 77
PROCEDURE FOR DISASSEMBLY AND REASSEMBLY	Page 78
DESCRIPTION OF MAIN CIRCUIT OPERATION	Page 80
SERVICE CALL Q & A	Page 87
PARTS LIST AND DIAGRAM	Page 114


# HITACHI



INDOOR UNIT

**RAK-VJ60PHAE**  
**RAK-VJ70PHAE**

(RC-AGS1EA0E)




Cooling & Heating

# air


# SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.




2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by the user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be  $1M\Omega$  or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again. If it is found not so strong and safe, the unit should be installed at the initial location after reinforced or at a new location.
10. Any inflammable object must not be placed about the location of installation.
11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



## WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

### 1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

### 2. Object parts

- (1) Micro computer
- (2) Integrated circuits (I.C.)
- (3) Field-effective transistor (F.E.T.)
- (4) P.C. boards or the like to which the parts mentioned in (1) and (2) of this paragraph are equipped.

### 3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing  $1M\Omega$  earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a solder iron

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument short circuit a load circuit or the like.

**⚠ CAUTION**

1. In quiet or stop operation, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
2. When it thunders nearby, it is recommend to stop the operation and to disconnect the power cord plug from the power outlet for safety.
3. In the event of power failure, the air conditioner will restart automatically in the previously selected mode once the power is restored. In the event of power failure during TIMER operation, the air conditioner will not start automatically. Re-press ON/OFF button after 3 minutes from when the unit off or power recovery.
4. If the room air conditioner is stopped by adjusting thermostat, or miss operation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
5. This room air conditioner should not be used at the cooling operation when the outside temperature is below  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).
6. This room air conditioner (the reverse cycle) should not be used when the outside temperature is below  $-15^{\circ}\text{C}$  ( $5^{\circ}\text{F}$ ).  
If the reverse cycle is used under this condition, the outside heat exchanger is frosted and efficiency falls.
7. When the outside heat exchanger is frosted, the frost is melted by operating the hot gas system, it is not trouble that at this time fan stops and the vapour may rise from the outside heat exchanger.

## SPECIFICATIONS

TYPE			DC INVERTER	
			INDOOR UNIT	INDOOR UNIT
MODEL			RAK-VJ60PHAE	RAK-VJ70PHAE
POWER SOURCE			1PHASE, 50Hz, 220 ~ 240V	1PHASE, 50Hz, 220 ~ 240V
COOLING	TOTAL INPUT	(W)	1,813 (500~3,050)	2,628 (500~3,150)
	TOTAL AMPERES	(A)	8.37~7.67	12.13~11.12
	CAPACITY	(kW)	6.00 (1.75~6.80)	7.10 (1.75~7.50)
		(B.T.U./h)	20,470 (5,970~23,200)	24,220 (5,970~25,590)
HEATING	TOTAL INPUT	(W)	2,000 (500~3,050)	2,611 (500~3,150)
	TOTAL AMPERES	(A)	9.23~8.46	12.05~11.04
	CAPACITY	(kW)	7.00 (1.75~7.80)	8.10 (1.75~8.30)
		(B.T.U./h)	23,880 (5,970~26,610)	27,640 (5,970~28,320)
DIMENSIONS (mm)		W	1050	1050
		H	294	294
		D	230	230
NET WEIGHT		(kg)	12.5	12.5



● The performance tests are based on the EN14511, EN14825.

※ After installation

MODEL	RAK-VJ60PHAE	RAK-VJ70PHAE
FAN MOTOR	38W	
FAN MOTOR CAPACITOR	NO	
FAN MOTOR PROTECTOR	NO	
COMPRESSOR	-	
COMPRESSOR MOTOR CAPACITOR	NO	
OVERLOAD PROTECTOR	NO	
OVERHEAT PROTECTOR	NO	
FUSE (for MICROPROCESSOR)	3.15A	
POWER RELAY	NO	
POWER SWITCH	NO	
TEMPORARY SWITCH	YES	
SERVICE SWITCH	NO	
TRANSFORMER	YES	
VARISTOR	S14K320E2G10AS5	
NOISE SUPPRESSOR	NO	
THERMOSTAT	YES(IC)	
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)	YES	
REFRIGERANT CHARGING VOLUME	PIPES	WITHOUT REFRIGERANT BECAUSE COUPLING IS FLARE TYPE

# Figure showing the Installation of Indoor Unit


MODEL RAK-VJ60PHAE  
RAK-VJ70PHAE



# HITACHI

## Remote Controller Manual

MODEL  
RC-AGS1EA0E




### Remote Controller manual

To obtain the best performance and ensure years of trouble free use, please read this instruction manual completely.

# Names and Functions of Remote Controller

- This controls the operation function and timer setting of the room air conditioner. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter.



## Backlight function

- Backlight is to see the LCD readings in the dark.
- On Pressing any key, the LCD panel lights up for a period of approx. 10 seconds. After approx. 10 seconds the light automatically switches off.
- The function is independent of all other functions of the air conditioner.
- The backlight color is white.

## Precautions for Use


- Do not put the remote controller under direct sunlight and high temperature.
- Do not drop it on the floor, and protect it from water.
- If you press the any function button during operation, the air conditioner may stop for about 3 minutes for protection before you can start it again.

# How to Install the Batteries in the Remote Controller

**1** Remove the cover as shown in the figure and take out the old batteries.



**2** Install the new batteries.  
The direction of the batteries should match the marks in the case.




## CAUTION

1. Do not use new and old batteries, or different kinds of batteries together.
2. Take out the batteries when you do not use the remote controller for 2 or 3 months.

## NOTE

- Change the batteries when remote controller LCD display restarts on pressing of any key and there is no response from air conditioner.

# How to set clock



**1**

Press and Hold Timer ON button or Timer OFF button for 5 seconds.

ON OR OFF segment start blinking on LCD approx. 5 seconds then Clock symbol start blinking.

**2**

When Clock symbol is in blinking, Press Temperature Up / Down



button to change/set desire time value.

**3**

Press Timer ON button or Timer OFF button once.

Clock symbol stop blinking and Clock time will be display on LCD screen.

## NOTE

- When Timer ON, Timer OFF or both set then it is not possible to change/set clock time. First Timer ON, Timer OFF or both need to cancel.
- If Correct clock time is not set then Timer ON and Timer OFF will not operate correctly.
- At time of Battery replacement/ Reset, Clock time need to set. If it is not set and press any key then default 12:00 will be set.
- At time of Battery replacement / Reset, Need to follow process from step2 onwards.
- During Clock time change/set when symbol is blinking, if no key press then it will come out of Clock setting with previous set time.

# Various Functions

## Auto Restart Control

- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode and airflow direction.  
(As the operation is not stopped by remote controller.)
  - If you intend not to continue the operation when the power is resumed, switch off the power supply. When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode and airflow direction.
- Note: 1. If you do not require Auto Restart Control, please consult your sales agent.  
2. Auto Restart Control is not available when Timer set.

## Auto Mode

The device will automatically determine the mode of operation, Heat Mode or Cool Mode depending on the current room temperature. The selected mode of operation will change when the room temperature varies.

**1** Press the Mode Selector Button so that the display indicates the  (Auto) mode of operation.

- When Auto has been selected, the device will automatically determine the mode of operation, Heat or Cool depending on the current room temperature.
- If the mode automatically selected by the unit is not satisfactory, manually change the mode setting (Heat, Dry, Cool or Fan).

**2** Set the desired Fan Speed with the  (Fan Speed) button (the display indicates the setting).

Auto  (Auto) →  (Silent) →  (Low) →  (Super High) ←  (High) ←  (Medium) ←

**3** Set the desired room temperature with the Temperature buttons (the display indicates the setting).  
The temperature setting and the actual room temperature may vary depending on conditions.  
Temperature range can be set between 16.0°C and 32.0°C.


**START/STOP** Press the  (On/Off) button.  
Operation starts with a beep.  
Press the button again to stop operation.

■ As the settings are stored in the memory of the remote controller, you only have to press the  (On/Off) button next time.

Press the  (Fan Speed) button to select Auto, Silent, Low, Medium, High or Super High.

# Heat Mode

- Use the device for heating when the outdoor temperature is under 21°C. When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to keep reliability of the device, please use this device above -15°C of the outdoor temperature.



**1**

Press the Mode Selector Button so that the display indicates

 (Heat).

**2**

Set the desired Fan Speed with the  (Fan Speed) button (the display indicates the setting).



**3**

Set the desired room temperature with the Temperature buttons (the display indicates the setting).

The temperature setting and the actual room temperature may vary depending on conditions.

Temperature range can be set between 16.0°C and 32.0°C.

**START  
STOP**

Press the  (On/Off) button. Heating operation starts with a beep. Press the button again to stop operation.


- As the settings are stored in the memory of the remote controller, you only have to press the  (On/Off) button next time.
- During Auto fan, the fan speed automatically changes as below:
  - When the difference between room temperature and setting temperature is large, fan starts to run at Super High speed.
  - After room temperature reaches the preset temperature, fan speed will be changed to lower speed to obtain optimum room temperature condition for natural healthy heating.

## ■ Defrosting

Defrosting will be performed about once an hour when frost forms on the heat exchange of the outdoor unit, for 5~10 minutes each time. During defrosting operation, the operation lamp blinks in cycle of 2 seconds on and 1 second off. The maximum time for defrosting is 20 minutes. (If the piping length used is longer than usual, frost will likely to form.)

# Dry Mode

Use the device for dehumidifying when the room temperature is over 16°C.  
When it is under 15°C, the dehumidifying function will not work.



1

Press the Mode Selector Button so that the display indicates  (Dry).

The fan speed is set at Auto.

Press  (Fan Speed) button to select Silent, Low or Auto fan speed.

2

Set the desired room temperature with the Temperature Buttons (the display indicates the setting).



The range of 20.0°C to 26.0°C is recommended as the room temperature for dehumidifying.  
Temperature range can be set between 16.0°C and 32.0°C.

START  
STOP

Press the  (On/Off) button. Dehumidifying operation starts with a beep. Press the button again to stop operation.


- As the settings are stored in the memory of the remote controller, you only have to press the  (On/Off) button next time.

## ■ Dehumidifying Function

- When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.  
When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.


# Cool Mode

Use the device for cooling when the outdoor temperature is -10 to 46°C.  
If humidity is very high (over 80%) indoors, some dew may form on the air outlet grille of the indoor unit.



## Powerful Operation

- By pressing  (Powerful) button during Auto, Heat, Dry, Cool, or Fan operation, the air conditioner performs at maximum power.
- During Powerful operation, cooler or warmer air will be blown out from indoor unit for Cooling or Heating operation respectively.



START

Press the  (Powerful) button during operation.

- "  " is displayed on the LCD.
- Powerful operation ends in 20 minutes. Then the system automatically operates with the previous settings used before Powerful operation.

CANCEL


- Press the  (On/Off) button. or
- Press the  (Powerful) button again.
- "  " disappears from the LCD.

### NOTE

- When SleepSense Smart Eco operation, LeaveHome Operation, Silent Mode or My mode is selected, Powerful Operation will be cancelled.
- During Powerful operation, capacity of the air conditioner will not increase
  - if the air conditioner is already running at maximum capacity.
  - just before defrost operation (when the air conditioner is running in Heating operation).

## LeaveHome Operation

- Prevent the room temperature from falling too much when no one is at home. The initial setting temperature is 10.0°C and the temperature range can be set between 10.0°C and 16.0°C.



START

- ① Press  (LeaveHome) button during stop or operation.  
Room temperature is set at 10.0°C and heating operation starts.
- ② Set the desired room temperature with the Temperature buttons. Temperature range can be set between 10.0°C and 16.0°C.
  - "  ", "  ", "  ", "Set Temperature" is displayed on the LCD.

CANCEL

- Press the  (On/Off) button. or
- Press the  (LeaveHome) button again.
- Change to other Operation Mode.


### NOTE

- During Leave Home operation, fan speed and horizontal and vertical air deflector position cannot be changed.
- Timer function will be cancel if LeaveHome key press.
- Powerful, SleepSense, Smart Eco, Timer Function, Silent, My Mode operations are disable.

## FrostWash Operation

- The dust and dirt adhering to indoor heat exchanger which is the cause of the smell. They are washed away by freezing and thawing of the heat exchanger.
- FrostWash function can work when the outdoor temperature is 1°C to 43°C and Indoor humidity is 30% to 70%.

### The process of FrostWash



- "  " lamp on the indoor unit lights up during FrostWash operation.
- When pressing "On/Off" button during FrostWash operation, FrostWash will stop.
- In order to protect the product, FrostWash function cannot be carried out again for about 60 minutes after FrostWash operation is completed.

## ■ FrostWash(Manual Mode)

When the unit is off, press  (FrostWash) button, manual FrostWash will start.


### ■ How to start and cancel FrostWash (Manual mode).

- Press the FrostWash button  , FrostWash  display on LCD screen.
  - FrostWash operation start with beep sound and "  " lamp light up on the indoor unit.
  - After one hour, "  " disappears from the LCD. After about two hours, the indoor unit will stop FrostWash operation.
  - In order to protect the product, FrostWash function cannot be carried out again for about 60 minutes after the FrostWash operation is completed.
- Press the  (On/Off) button, the operation will stop.
  - "  " lamp on the indoor unit turns off.

## Precautions for Use

- Do not open windows or doors during FrostWash operation. Water will condense on the air deflector and drips down occasionally. This will wet your furniture.
- Do not open or remove the front panel during FrostWash operation. It may cause injury or malfunction.
- FrostWash operation does not wash away all dust and dirt.
- Hissing, fizzy or squeaking noise may generate during FrostWash operation.
- If the air conditioner is continuously running, FrostWash function is not effective.
- During FrostWash operation, if power is turned off and then power is restored, FrostWash function will not restart.
- After turning on the power, please wait a moment if you want to start FrostWash.
- If On Timer or Off Timer is set, there is a need to cancel those timer before operating FrostWash.

# FrostWash(Auto Mode)



## ■ How to enable FrostWash ( Auto )

1

- Press Temperature Up button and FrostWash button for 3 seconds together while remote control in OFF mode with directing remote control towards Indoor unit.  
 is displayed on the LCD indicating Auto FrostWash enable.
- If FrostWash function is not being used for a long period, it may not be possible to completely remove the dust and dirt adhering to indoor heat exchanger. This will cause odour. Hence, kindly operate FrostWash frequently by using the remote controller.


## ■ How to disable FrostWash (Auto)

2

- Press Temperature Down button and FrostWash button for 3 seconds together while remote control in OFF mode with directing remote control towards Indoor unit.  
 disappear on the LCD indicating Auto FrostWash disable.
- The screen on remote controller.  
When FrostWash (Auto) is enabled, " " is displayed on the LCD.  
When FrostWash (Auto) is disable, " " is disappeared on the LCD.

## FrostWash auto start conditions

Accumulated operating hours of the air conditioner have exceeded 42 hours  
 +  
 Air conditioner is operated for more than 30 minutes and stops, such as cooling operation  
 +  
 Human sensor detects somebody is in room for 15 minutes and over 4 times; or not in room for 15 minutes




- When the outdoor temperature or indoor humidity are not suitable for FrostWash operation, only fan operation is carried out, FrostWash operation will be done again when room air conditioner is in standby mode.
- Sometimes the heat exchanger may not freeze depending on the conditions of the room.
- When the ON timer reaches the set time during FrostWash operation, it will stop the FrostWash operation and start the operation of setting mode.
- If the interval of the OFF to ON timer is less than 2 Hours , FrostWash operation may not be complete. In that case, it will restart FrostWash operation when room air conditioner is in standby mode.
- To return to normal FrostWash (Auto mode) interval (42 hours), please stop operation of air conditioner and operate FrostWash (Auto mode) or FrostWash (Manual mode).
- When FrostWash operation has not been operated in last 84 hours , FrostWash kicks in automatically after halting the operation even if a human sensor detects a person in the room.
- When FrostWash is stopped during FrostWash operation, the unit automatically restart FrostWash operation at the next operation stop.

# Mold Guard Operation

- After the cooling operation is stopped, the fan of the indoor unit is dried by heating or fan mode to suppress the generation of mold inside the indoor unit.
  - Mold Guard Operation period is about 100 minutes.
  - It can't remove mold or sterilize.

## The Process of Mold Guard



- “” Lamp on the indoor unit lights up during Mold Guard operation.
- If the air conditioner is operated in cooling or drying mode, including in auto mode, for more than 10 minutes and then put into off mode, the mold guard operation will start.
- If unit operation is stopped after heating operation, Mold Guard will not operate.
- Room temperature or humidity may rise.

## ■ How to set and cancel Mold Guard

### For setting

- Press the room temperature Up button  and Timer on  button for 3 seconds together while remote controller in OFF mode with directing remote control towards indoor unit. “” is displayed on the LCD.

### For cancelling

- Press the room temperature Up button  and Timer on  button for 3 seconds together while remote controller in OFF mode with directing remote control towards indoor unit.
- “” is disappear on the LCD.
- Once Mold Guard function set, Mold Guard icon will always display on the LCD. And it stored in the memory of remote controller and remain set even after reset or battery replacement case. It is one time setting procedure to use this function.

## ■ How to stop at middle point of Mold Guard operation


- Press the  button (On/Off) twice, the operation will stop.
- “” Lamp on the indoor unit turns off. But setting for Mold Guard will not cancel, it will stop operation only.

## NOTE

- If unit operation is stopped after heating operation, Mold Guard will not operate.
- If operation of Unit is stop by Off Timer, the Mold Guard will not operate.
- If On Timer is set and on time is within about 2 hours, the Mold Guard will not operate.
- Depending on situation, Mold Guard will operate with Fan Mode.
- Room temperature or humidity may rise.
- When there would be the window near indoor unit, the water might condense on the window during Mold Guard. If necessary, to cancel Mold Guard.

# Smart Eco operation

- The sensor detects the presence of people in the room. When nobody is detected, the unit automatically starts energy saving operation by shifting the set temperature in two steps.
- Smart Eco button is scrolling button , First Press of button , it will start Eco operation , on second Press of button it will start Eco with Auto-Off operation and on Third press of button , it will cancel Eco and Eco with Auto-Off function.



Key Press	1	→ 2 →	3
Function Selected	Eco	Eco+Auto-Off	Cancel


## To Start Smart Eco operation

- Press the Smart Eco button  during Heat, Auto , Cool or Dry operation , the Air conditioner performs the "Eco" operation.

 is display on LCD screen.

- A beep sound is emitted from Indoor Unit.

The sensor starts to detect the presence of people in the room. Energy saving operation will start by changing the set temperature higher or lower automatically and reducing operation power consumption.



## To Start Eco operation and Auto-Off operation

- Press the Smart Eco button  again, it will start Auto-Off operation along with Eco operation.

Sensor detect activity / movement level in room and turn off the unit automatically , thus achieving the purpose of energy saving during day time.

 and **AUTO OFF** will be appear on LCD.

- A beep sound is emitted from indoor unit .

## To Cancel Eco operation and Auto-Off operation

- Press the  start/stop button OR
- Press the Smart Eco button  again.

### NOTE


In case the power consumption is already low, Smart Eco operation will not reduce the power consumption.

- By pressing (POWERFUL) button, Eco or Eco with Auto-Off operation is cancelled.
- After auto restart, Eco or Eco with Auto-Off operation is cancelled and previous operation mode shall start.
- By Pressing Mode button ,Leave Home button , SleepSense button , My mode button , Eco or Eco with Auto-Off operation is cancelled.


# Smart Eco Logic

When the presence of people is not detected for 20 minutes, the set temperature is automatically shifted for energy saving. If nobody is in the room for 60 minutes, the set temperature is shifted further.

Cooling operation [diagram representation for illustrative purpose only]



Heating operation [diagram representation for illustrative purpose only]



The unit returns to normal operation when the sensor detects human movement.


The set temperature is adjusted automatically, but the temperature display on the remote controller does not change.

## NOTE

The sensor detects changes to the infrared generated by human bodies. Therefore the accuracy of sensor may be affected in the following cases:

- The activity level is very low ( reading , watching TV, etc.) or human bodies are blocked by a screen , cabinet or glass board.
- The Indoor temperature is very high and exceeds or approaches the human body temperature ( When refrigeration just begins)
- Person wears thick clothes and turns his/her back to the air conditioner.
- Curtains or plant leaves swing due to pet movement or airflow.

## Smart Eco with Auto-Off Logic



The motion before Auto-Off ( Operation stop)

- If the Unit cannot find any person during Eco with Auto-Off operation for 60 minutes , the operation stops automatically.
- The operation does not restart if person comes back to the room after stopping the operation. User need to restart operation by remote controller.
- During OFF Timer operation , Priority is given to OFF timer operation.

## NOTE

- If there are infants or a person who is on bed due to sickness , it is recommended not to set "Auto-Off" Unit may judge that nobody is in the room and stop the operation of the Unit.
- In following cases , the operation may stop automatically
  - If there is a person in the place where human sensor cannot detect it presence.
  - If there is a sleeping person to little child only.
  - If there is pet only.


In these cases it is recommended to cancel Auto-Off function.

## Power Safe (Max Current Switching )

- This function limit the maximum current during the operation of Air conditioner so it will help to avoid breaker trips if maximum current reaches to breaker limit. it limits the electrical current during operation.

When Power Safe set , Maximum current limit for model changes as below.

Model	Maximum current with Power Safe setting
1.8~3.5kW	6A
4.2~5.0kW	8A



### How to set Power Safe mode (Power Safe)

**START**

- Place the indoor unit in the standby mode ( OFF mode on the display of remote controller)
- Press temperature down button  and Up/Down swing button  about 3 seconds together with directing remote control toward indoor unit.
-  symbol will be visible on LCD screen and indoor unit will accept by buzzer sound.

### How to cancel Power Safe mode

**CANCEL**


- Place the indoor unit in the standby mode ( OFF mode on the display of remote controller)
- Press temperature down button  and Up/Down swing button  about 3 seconds together.
-  symbol will be disappear on LCD screen and indoor unit will accept by buzzer sound.

### NOTE

- Once Power Safe mode set ,it stored In the memory of remote controller and remain set even after remote controller reset or battery replacement case.
- Power Safe mode symbol will be visible in all mode if it set. It is one time setting procedure to use this function.
- This function will limits the maximum current drawn by air conditioner by reducing the speed of the compressor, you may feel less cooling or heating performance compare to normal mode. If you feel so please cancel Power Safe mode if Power Safe mode is set .
- At heating operation or Cooling operation during Power Safe setting maximum capacity will decrease.
- During Power Safe setting mode , it is recommeded to use Auto Fan speed.

# SleepSense Operation

- With motion sensor, the room air conditioner detects movements, its location and temperature around people to control set temperature and control fan speed to provide comfortable and energy saving operation as well as to achieve comfortable sleep environment.



## To Start SleepSense operation

- Press the SleepSense button  during Cool and Heat operation , the Air conditioner performs the "SleepSense" operation.  is display on LCD screen.

A beep sound is emitted from Indoor Unit.

Energy saving operation will start by changing the set temperature higher or lower automatically and reducing operation power consumption.

## To Cancel SleepSense operation

- Press the  start/stop button OR Press the SleepSense button  again. OR Mode  button.  will be disappear on LCD.

A beep sound is emitted from indoor unit.

### NOTE

The sensor detects changes to the infrared generated by human bodies. Therefore the accuracy of sensor may be affected in the following cases:

- The activity level is very low ( reading , watching TV, etc.) or human bodies are blocked by a screen , cabinet or glass board.
- The Indoor temperature is very high and exceeds or approaches the human body temperature ( When refrigeration just begins)
- Person wears thick clothes and turns his/her back to the air conditioner.
- Curtains or plant leaves swing due to pet movement or airflow.

### NOTE

- By pressing (Powerful mode) button, SleepSense operation is cancelled.
- After auto restart, SleepSense operation is cancelled and previous operation mode shall start.
- By Pressing Leave Home button, Smart ECO button/ECO button , My Mode button , SleepSense operation is cancelled.


# SleepSense Operation

## LOGIC ( SleepSense)

- At First, unit will operate cooling mode for 60 minutes at setting condition.
- With the motion sensor, the room air conditioner can monitor human movement. If no human movement is detected, then the temperature will increase by 1°C ( in case of cooling operation ) automatically and The fan speed will be changed to silent fan speed.  
Unit continues running for another 1 hour.
- If the condition of activity in the room is stable then the unit will continue running with the temperature increased by another 1°C (in case of cooling) respectively.
- During the SleepSense operation, if Big activity /movement is detected, the temperature and Fan speed will resume back to previous setting.
- During the SleepSense operation, if small activity /movement is detected, the temperature will decreased by 1°C.

# AQtiv-Ion

By pressing  (AQtiv-Ion) button during Heat, Auto, Cool, Dry, Fan operation, the AQtiv-Ion operation start.



**1**

To Start AQtiv-Ion operation

Press the AQtiv-Ion button  .  is display on LCD screen.

**2**

To Cancel AQtiv-Ion operation


Press the  start/stop button.

Press the AQtiv-Ion button  again.

 will be disappear on LCD.

# Silent Mode

By pressing the  (Silent) button during Auto, Heat, Dry, Cool or Fan operation, the fan speed changes to the silent fan speed  .



## START

- When  (Silent) button is pressed,
- “” is displayed on the LCD.
- Fan speed changes to silent  .

## CANCEL

- Press the  (On/Off) button, or
- Press the  (Silent) button once again or
- Press the  (Fan Speed) button.

Fan speed will return to the previous speed before Silent operation starts.


When Silent operation stops, “” will disappear from the LCD.

## NOTE

- When Powerful operation is selected, Silent operation will be cancelled. Fan speed will return to the previous speed before Silent operation.
- After unit auto restart, Silent operation is cancelled. Fan speed will return to the previous speed before Silent operation.
- During any operations with silent fan speed  , if user presses the  (Silent) button, the fan speed does not change.
- By Pressing Mode button or LeaveHome button or My Mode button , Silent operation is cancelled.

# Fan Mode

User can use the device simply as an air circulator.




# Adjusting the Airflow Direction(upward and downward)

- 1** Adjust the airflow upward and downward. According to operation, the horizontal air deflector is automatically set to the proper angle suitable for each operation. The deflector can be swung up and down and also set to the desired angle using the “ (Up/Down)” button.
- Press the “ (Up/Down)” button. The deflector will start to swing up and down.
- “” is display on LCD screen.
- Press the “ (Up/Down)” button again. The deflector(s) will stop in the current position.
- “” is disappear on LCD screen.

- If the “ (Up/Down)” button is pressed once, the horizontal air deflector swings up and down. If the button is pressed again, the deflector stops in its current position. Several seconds (about 6 seconds) may be required before the deflector starts to move.
- When the operation is stopped, the horizontal air deflector moves and stops at the position where the air outlet closes.

## CAUTION

- Don't operate the deflector by hands. It might cause of the failure.
- In “Cooling” operation, do not keep the horizontal air deflector swinging for a long time. Some dew may form on the horizontal air deflector and some dew may drop from it.



# Adjust the Airflow Direction(leftward and rightward)

## 1 Adjusting the airflow leftward and rightward parallelly.


Adjustment of airflow in Left and Right direction.

- Press the Left/Right button . The deflector(s) will start to swing Left and Right side parallelly.  is display on LCD screen.
- Press the Left/Right button  again. The deflector(s) will stop at the current position.  Is disappear on LCD screen.

- If the “  ” button is pressed once, the Vertical air deflector swings Left and Right.If the button is pressed again, the deflector stops in its current position. Several seconds (about 6 seconds) may be required before the deflector starts to move.
- When the operation is stopped, the vertical air deflector moves and stops at the center position.

### CAUTION

- Don't operate the deflector by hands. It might cause of the failure.
- In "cooling" operation don't keep the vertical air deflector at leftmost or rightmost position or swinging for a long time. Dew formation may happen on vertical deflector and some water drops may fall from it.




## 2 Adjust the airflow leftward and rightward asymmetrically.

- Press the Wide Reach button . The deflector(s) will start to swing Left and Right side symmetrically.  Is display on LCD screen.
- Press the Wide Reach button  again. The deflector(s) will stop at the current position.  Is disappear on LCD screen.

- If the “  ” button is pressed once, the Vertical air deflector swings Left and Right symmetrically. If the button is pressed again, the deflector stops in its current position. Several seconds (about 6 seconds) may be required before the deflector starts to move asymmetrically.
- When the operation is stopped, the vertical air deflector moves and stops at the center position.

### CAUTION


- Don't operate the deflector by hands. It might cause of the failure.
- In "cooling" operation don't keep the vertical air deflector at leftmost or rightmost position or swinging for a long time. Dew formation may happen on vertical deflector and some water drops may fall from it.



# Timer Reservation

## 1. Off Time Setting

The device can be set to turn off at a preset time.




1

- Press  ( Timer OFF) Button to select OFF timer.
-  Symbol start blinking and 12:00 or Previously set time will be display on LCD screen.
- Set up desire Turn off time by pressing Temperature Up /Down button .
- After setting , point the remote controller towards the indoor unit and Press  button.  
 Symbol stop blinking and turn off time will be display on LCD screen.  
A beep sound emitted from Indoor unit and Timer LED on the indoor unit lights up.  
Remote controller will go to OFF mode after turn off time elapse.
- By pressing On Timer and Off Timer Button together for 3 seconds, Off Timer can be canceled.

## 2. On Time Setting

Indoor unit can be set to turn on at a preset time.



2

- Press  ( Timer ON) Button to select ON timer.
-  Symbol start blinking and 12:00 or Previously set time will be display on LCD screen.
- Set up desire Turn on time by pressing Temperature Up / Down button .
- After setting , point the remote controller towards the indoor unit and Press  button.  
 Symbol stop blinking and turn on time will be display on LCD screen.  
A beep sound emitted from Indoor unit and Timer LED on the indoor unit lights up.  
Remote controller will go to ON mode after ON timer elapse.
- By pressing On Timer and Off Timer Button together for 3 seconds, On Timer can be canceled.

### NOTE


- During the Timer Setting, if you do not press the Temperature Up/Down key within 10 seconds then it will come out of the Timer Setting without any changes in Timer Settings and will display with  or  Icon will be stable appear on LCD to indicate Timer Setting if set previously.
- During Timer setting mode, if you press any key then it will come out immediately from timer setting.
- Timer ON and Timer OFF can be set simultaneously.
- When both timer set simultaneously then  on LCD appear with Timer which will going to execute/expire first.
- During Timer ON or Timer OFF set then Clock setting can not be changed. Clock time will not be display on LCD screen.
- Clock time can be seen on LCD screen by Press and Hold Timer ON or Timer OFF key for 5 seconds. Clock time display for 10 seconds then it will change to Timer ON or Timer OFF time value.

# Initialization of the Built-in airCloud Home Module

- You can reset the internal settings (restore the factory settings) by remote controller.

## ■ How to restore factory setting

Please make this setting with the remote control in off mode.



- Press  button (Mode) and  button (On Timer) 3 seconds together.
- LCD will display “ — — ” on Temperature segment for 3 seconds then it will display normal screen.
- Make sure “  ” Lamp on the indoor unit flash 4 times repeatedly for about 20 seconds.
- Restart the unit & check “  ” Lamp blinks 3 times. This ensures that unit enters into pairing mode & restoring factory setting is succeeded.

### NOTE


- Please note that the configuration will be cleared and pairing procedure will be required to do again to use the built-in airCloud Home module.
- Please refer separate operation manual available for more information related Built-in airCloud Home Module.

"Wi-Fi" is a trademark or registered trademark of the "Wi-Fi Alliance".

# My Mode(Programming)

- Use this mode for personalized comfortable settings. The My Mode can be set by using the remote controller.
- Up to 3 programs can be set.

## Programming of My Mode



### Default Setting of My Mode

My Mode	Mode	Temperature	Fan Speed	ON Timer / OFF Timer	Silent
My Mode1	COOL	25. C	Auto	No setting	No setting
My Mode2	COOL	25. C	Auto	No setting	No setting
My Mode3	COOL	25. C	Auto	No setting	No setting

### Enter to My Mode programming

- Press the My Mode button continuously for 5 seconds .
  - " " blinks on the LCD. And " | ", " 2 " or " 3 " any one appear at the right of " " .
  - The blinking of " " will remain for 10 seconds.
  - By pressing the (My Mode) button, " | ", " 2 " or " 3 " can be selected for programming.

### Mode Selection

- Press (Mode) button in order to select desired Mode during " " blinks.
  - Mode will change from (Heat) → (Auto) → (Cool) → (Dry) → (Fan) cyclically.

### Fan Speed Selection

- Press (Fan Speed) button in order to select desired Fan Speed during " " blinks.
  - Available Fan speed only can be selected as per selected desired mode.

### Desired Room Temperature Selection



- Press (Temp Up) button or (Temp Down) button in order to select desired Room Temperature during " " blinks.
  - Temperature range can be set between 16.0°C and 32.0°C .
  - Fan Mode can not be set desired Room Temperature.

### Silent Mode Selection

- Press (Silent) button in order to set or cancel Silent Mode during " " blinks.

# My Mode(Programming)

## Programming of My Mode



### On Timer Setting

6

- Press  ( Timer ON) Button to select ON timer.
-  ON Symbol start blinknig on LCD screen.
- ON Timer time will be display on clock time segment on LCD.
- Press  button to set desire ON timer.
- Press  button . It will set ON timer programming.
-  ON symbol stop blinking on LCD screen.
- Remote controller will go to ON mode after ON timer elapse.
- To cancel ON timer , Press On Timer button and Off Timer button together for 3 seconds.

### Off Timer Setting

7

- Press  ( Timer OFF) Button to select OFF timer.
-  OFF Symbol start blinknig on LCD screen.
- OFF Timer time will be display on clock time segment on LCD.
- Press  button to set desire OFF timer.
- Press  button . It will set OFF timer programming.
-  OFF symbol stop blinking on LCD screen.
- To cancel Off timer , Press On Timer button and Off Timer button together for 3 seconds.
- Remote controller will go to OFF mode after OFF timer elapse.

### Register of My Mode Programming

8


- Once all desire setting completed , press  (On/Off) button during "  " blinks.
- All selection will be saved to remote controller and room air conditioner.

### NOTE

- If operation of remote controller will not be done for 10 seconds during My Mode programming, remote controller will come out from My Mode programming without registering of My Mode Programming. Without registering of My Mode Programming, My Mode selection will remain with all previously selections and previous values.
- If My Mode button is kept pressing for 5 seconds during My Mode Programming, remote controller will come out from My Mode programming. Without registering of My Mode Programming, My Mode selection will remain with all previously selections and previous values.
- If battery is replaced or  (Reset) button is pressed, My Mode Programming on remote controller will be reset to default settings. If new settings are required, do My Mode Programming again.
- When Operation Mode Lock is set, selectable mode during My Mode will be limited.


# My Mode(Start or Stop of My Mode Operation)

## Start of My Mode Operation




### Start of My Mode Operation

- Press  (My Mode) button at room air conditioner operation.  
Room air conditioner starts with My Mode 1 registered to remote controller.
- Press  (My Mode) button again in order to change to the operation of My mode 2, My mode 3.



## Stop of My Mode Operation



### Stop of My Mode Operation


- Press  (On/Off) button in order to turn off room air conditioner.

### NOTE

- My Mode operation can be cancelled by pressing  (Mode) button or  (LeaveHome) button.
- If My Mode Operation is started without programming of My Mode yet, room air conditioner starts with default setting of My Mode.
- If On Timer or Off Timer set by My Mode has elapsed, pressing  (My Mode) button again to restart the Timer operation.
- FrostWash (Manual Mode) will not activate during My Mode.
- Up/Down swing , Left-Right swing , Wide Reach and AQtiv-Ion function can be selectable with My mode.

# Operation Mode Lock

The remote controller can be set to fix the Heat Mode (including Fan Mode), Cool Mode and Dry Mode (including Fan Mode) operations.



## ■ Method to lock Heat Mode (including Fan Mode) operation.

Press  (Mode) and  buttons simultaneously for about 3 seconds when the remote controller is OFF.

“ ”, “ ” and “ ” will be displayed for about 10 seconds. Later, “ ” and “ ” will remain.

This indicates that Heat Mode operation is locked.

When pressing  (Mode) button, “ ”, or “ ” will be displayed.

## ■ Method to unlock Heat Mode (including Fan Mode) operation.

Press  (Mode) and  buttons simultaneously for about 3 seconds when the remote controller is OFF.

All operation mode symbols will appear on the display for about 10 seconds “ ” will disappear. After that, “ ” will remain.

This indicates that Heat Mode operation is unlocked.

## ■ Method to lock Cool Mode and Dry Mode (including Fan Mode) operations.

Press  (Mode) and  buttons simultaneously for about 3 seconds when the remote controller is OFF.

“ ”, “ ”, “ ” and “ ” will be displayed for about 10 seconds. Later, “ ” and “ ” will remain.

This indicates that Cool Mode and Dry Mode operation is locked.

When pressing  (Mode) button, “ ”, “ ”, or “ ” will be displayed.

## ■ Method to unlock Cool Mode and Dry Mode (including Fan Mode) operations.

Press  (Mode) and  buttons simultaneously for about 3 seconds when the remote controller is OFF.


All operation mode symbols will appear on the display for about 10 seconds “ ” will disappear. After that “ ” will remain.

This indicates that Cool Mode and Dry Mode operation is unlocked.

### NOTE

- Operation Mode Lock function will not activate if Timer reservations or My Mode is activate. Timer reservations shall be deactivated first. Then, Operation Mode Lock function can be activated.
- Operation Mode Lock can be kept even if  (Reset) button is pressed.
- Operation Mode Lock will not be set if FrostWash(Manual Mode) is in progress.
- LeaveHome button is disable during lock Cool mode and Dry Mode operation.

## How to Reset Filter Sign on the indoor unit



Filter Sign on the indoor unit will show with “” lamp by blinking with 1 second on and 4 seconds off. Because cleaning of Air filter has not been done for a long time. Clean the Air filter.


Press Filter Button at Off Mode pointing the remote controller towards the indoor unit to reset Filter Sign.

“” symbol will be visible on LCD screen for about 3 seconds and Filter Sign on the indoor unit will turn off.

### NOTE

- Filter Button is active in OFF mode only.

## Reset Function ( For Hardware Reset)



During Battery replacement or any unlikely event, if the display does not change on Press of key or any unwanted garbage display comes, Press Reset button to reset your remote controller hardware.

In order to reset remote controller hardware , Press and release Reset button, the display will be as shown for 2 seconds then it will change to default mode screen.

### NOTE

- Use some pointed item like pen to press the reset key.
- Once the remote controller is reset, all setting will reset except some special function activated by User



# SAFETY PRECAUTION

- Please read the "Safety Precaution" carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of "▲ Warning" and "▲ Caution". The "Warning" section contains matters which, if not observed strictly, may cause death or serious injury. The "Caution" section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The sign indicate the following meanings.

 Make sure to connect earth line.	 The sign in the figure indicates prohibition.
 Indicates the instructions that must be followed.	

 <b>WARNING</b>	This symbol shows that this equipment uses a flammable refrigerant. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.
 <b>CAUTION</b>	This symbol shows that the Operation Instructions should be read carefully.
 <b>CAUTION</b>	This symbol shows that a service personnel should be handling this equipment with reference to the Installation Manual.
 <b>CAUTION</b>	This symbol shows that there is information included in the Operation Manual and/or Installation Manual

- Please keep this manual after reading.

## PRECAUTIONS DURING INSTALLATION

 <b>WARNING</b>	<ul style="list-style-type: none"> <li>• Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself. </li> <li>• Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.</li> </ul>
	<ul style="list-style-type: none"> <li>• Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock. </li> <li>• Be sure to use the specified piping set for R32. Otherwise, this may result in broken copper pipes or faults.</li> <li>• Do not use refrigerant other than the one indicated on the outdoor unit (R32) when installing, moving or repairing. Using other refrigerants may cause trouble or damage to the unit, and personal injury.</li> </ul>
 <b>CAUTION</b>	<ul style="list-style-type: none"> <li>• A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists. </li> <li>• Do not install near location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.</li> <li>• Please ensure smooth flow of water when installing the drain hose.</li> <li>• Do not install the indoor unit in a machine shop or kitchen where vapor from oil or its mist flows to the indoor unit. The oil will deposit on the heat exchanger, thereby reducing the indoor unit performance and may deform and in the worst case, break the plastic parts of the indoor unit.</li> </ul>

## PRECAUTIONS DURING SHIFTING OR MAINTENANCE

 <b>W A R N I N G</b>	<ul style="list-style-type: none"> <li>• Should abnormal situation arises (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation. </li> </ul>
	<ul style="list-style-type: none"> <li>• Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.</li> </ul>
	<ul style="list-style-type: none"> <li>• Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.</li> </ul>
	<ul style="list-style-type: none"> <li>• If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service/parts centers.</li> </ul>
	<ul style="list-style-type: none"> <li>• If the air conditioner is not cool, one possible cause could be due to refrigerant leakage, so consult your dealer. The refrigerant gas used in the air conditioner is harmless. But if refrigerant gas leaks into the room, harmful products are generated when in contact with fire from appliances such as a stove heater. When there is refrigerant gas accumulation in the room, immediately stop the air conditioner. Open the windows for ventilation and contact your agent.</li> </ul>

## PRECAUTIONS DURING OPERATION

 <b>W A R N I N G</b>	<ul style="list-style-type: none"> <li>• Avoid an extended period of direct air flow for your health. </li> </ul>
	<ul style="list-style-type: none"> <li>• Do not insert a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Before cleaning, be sure to stop the operation and turn the breaker OFF. </li> </ul>
	<ul style="list-style-type: none"> <li>• Do not use any conductor as fuse wire, this could cause fatal accident. </li> </ul>
	<ul style="list-style-type: none"> <li>• During thunder storm, disconnect and turn off the circuit breaker. </li> <li>• Spray cans and other combustibles should not be located within a meter of the air outlets of both indoor and outdoor units. As a spray can's internal pressure can be increased by hot air, a rupture may result. </li> </ul>



## PRECAUTIONS DURING OPERATION

- The product shall be operated under the manufacturer specification and not for any other intended use.



- Do not attempt to operate the unit with wet hands, this could cause fatal accident.

- When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.



- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.



- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.

- Do not use any aerosol or hair sprays near the indoor unit. This chemical can adhere on heat exchanger fin and blocked the evaporation water flow to drain pan. The water will drop on tangential fan and cause water splashing out from indoor unit.



- Please switch off the unit and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.




- Turn off the circuit breaker if the unit is not to be operated for a long period.



- Do not climb on the outdoor unit or put objects on it.

- Do not put water container (like vase) on the indoor unit to avoid water dripping into the unit. Dripping water will damage the insulator inside the unit and causes short-circuit.



- Do not place plants directly under the air flow as it is bad for the plants.

- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.

- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.




C  
A  
U  
T  
I  
O  
N

## Operation Range

Operation mode	Cooling/Dehumidifying	Heating
Outdoor temperature	-10 to 46°C	-15 to 21°C

## Names and Functions of Each Part

### Indoor Unit



### Model Name and Dimensions

MODEL	WIDTH (mm)	HEIGHT (mm)	DEPTH (mm)
RAK-VJ60PHAE RAK-VJ70PHAE	1050	294	255

# Names and Functions of Each Part

## Indoor Unit Indications



### Operation Lamp (Yellow)

This lamp lights during operation. The Operation Lamp flashes in the following cases during heating.

- (1) **During preheating**  
For about 2-3 minutes after starting up.
- (2) **During defrosting**  
Defrosting will be performed about once an hour when frost forms on the heat exchanger of the outdoor unit, for 5-10 minutes each time.



### Timer Lamp (Orange)

This lamp lights when the timer is working.

### Wi-Fi Lamp (Blue)

### Clean Function Lamp (Green)

This lamp uses for FrostWash, Mold Guard, Filter Sign.

### Temporary Switch

Use this switch to start and stop when the remote controller does not work.


- By pressing the temporary switch, the operation is done in automatic mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

**⚠ CAUTION**  
Turn off the circuit breaker if the unit is not be operated for a long period.

☆ If the power stays on and the unit is not operated, power is slightly consumed in the control circuit. The power is saved by turning off the power switch (or the circuit breaker when the power is supplied from the outdoor unit).


### ■ Attaching the air purifying filters (Accessories) to the filter frame.

- Attach the air purifying filters to the C-case to the designated position.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air purifying filters are used.
- The air purifying filters are not washable. It is recommended to use vacuum to clean. It can be used for 1 year. When you want to renew it, please ask your sales agent.



# Names and Functions of Remote Controller

This controls the operation function and timer setting of the room air conditioner. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter.



## Backlight function

- Backlight is to see the LCD readings in the dark.
- On Pressing any key, the LCD panel lights up for a period of approx. 10 seconds. After approx. 10 seconds the light automatically switches off.
- The function is independent of all other functions of the air conditioner.
- The backlight color is white.


## Precautions for Use

- Do not put the remote controller under direct sunlight and high temperature.
- Do not drop it on the floor, and protect it from water.
- If you press the FUNCTION button during operation, the air conditioner may stop for about 3 minutes for protection before you can start it again.

# Operate Air Conditioner with Smartphone

## Built-in airCloud Home module

airCloud Home is a cloud-based solution for remotely controlling your Hitachi air conditioning system via smart phone. You can operate the air conditioner from outside the home with your smartphone and check the operating status.



# What You Should Confirm When Using the Service

## Internet environment at home

- In order to use the service, FTTH (optical fiber) ADSL / CATV (cable TV) and other Internet services, a broadband line capable of communication is required. Not available on dial-up lines.
- For details on Internet connection, contact your provider or carrier. Please check your contract.
- Internet communication charges are the responsibility of the customer.

## Smartphone

- iOS (iPhone, etc.) 10.0 / Android 8.0 or later (as of December 2021).
- To confirm the OS version, check on your smart phone, or contact your smart phone manufacturer.
- Make sure that you can connect to the router with wireless LAN.
- Tablets are not guaranteed to work.

## Wireless LAN router (Hereinafter router)

- Please use a router that supports the 2.4GHz band.
- For security, be sure to use a router that can set the encryption method WPA2 or WPA (either TKIP or AES). We recommend the WPA2 (AES) encryption method. For the setting procedure, refer to the instruction manual of the router.
- Routers that support only WEP cannot be used.
- Mobile routers are not guaranteed to work.

## Initial Settings

### Please install the airCloud Home app on your smartphone

- (1) Search for the airCloud Home app
  - For Android models: Open Google Play. Android is a trademark and registered trademark of Google LLC.
  - For iOS models (iPhone): Open the App Store. iPhone is a trademark and registered trademark of Apple Inc.
- (2) Please install according to the screen
  - In order to use the dedicated app, you need to read and agree to the Terms of Service.
  - To dedicated application is free of charge, but to download the application, the data charges as per the internet provider or smart phone network provider charges apply.
  - The names and icons of the dedicated apps are as of September 2021. It may be changed by updating the application.

#### Notes:

- The first registered user becomes group administrator by default and manage other users and also set access rights for other users.
- When using with multiple users, the registered user should invite other users to register.

## Notes on Wireless LAN

### ⚠ WARNING


- **Do not enable remote features near those with a cardiac pacemaker or defibrillator**  
If it is too close, radio waves may affect the operation of pacemakers and other devices.

### Use frequency band

In the frequency band used by this air conditioner, in addition to industrial, scientific and medical equipment such as microwave ovens, private radio stations for identification of mobile objects (radio stations that require a license) and special Low power radio stations (radio stations that do not require a license) and amateur radio stations (radio stations that require a license) are in operation.

- (1) Before using this air conditioner, make sure that local radio stations for identification of mobile objects, specified low-power radio stations and amateur radio stations are not operating nearby.
- (2) If any harmful radio interference occurs from the air conditioner to the mobile station identification radio station, immediately stop using the radio wave and contact below to consult about measures for avoidance.
- (3) In addition, if you have any problems such as harmful radio interference from the air conditioner to the specified low power radio station for identifying the moving object or amateur radio station. Please contact us.

How to use frequency



It means that the entire band from 2.400 GHz to 2.4835 GHz can be used and the band of the mobile identification device can be avoided.

## Equipment certification

This air conditioner has a built-in wireless device that has been approved for construction design based on the Radio Law, so a license for a wireless station is not required. However, the following acts are prohibited by the Radio Law.

- Disassemble / modify wireless device.
- Remove the main unit nameplate.
- Erase the indication on the nameplate of the main unit.

## Security measures

- Since wireless LAN transmits and receives using radio waves, there is a risk of unauthorized access. Please take security measures for the wireless LAN router (hereinafter, router) to ensure data security. Please note that we do not take any responsibility if a problem occurs without implementing security measures.
- We recommend that you set a password (encryption key) for the router of at least 8 characters and no more than 63 characters. (Refer to the instruction manual of the router for the limitation of the number of characters.) When you change the password (encryption key), change the setting according to "When the router is replaced" in the airCloud Home app.

## About firmware

- This air conditioner has the function of connecting to our server through the Internet and automatically updating its firmware to the latest version. During the update, wireless communication may be interrupted and communication may be interrupted or can be slow.
- Do not analyze or modify the firmware.

## Usage restrictions

Please note the following restrictions on use. The Company will not be liable for any failure to observe the restrictions or for any incidental damage resulting from the use or inability to use the air conditioner.

- Do not connect to wireless networks for which you do not have usage rights. Unauthorized wireless networks (\*SSID) that you do not have permission to use may be displayed during automatic search of the wireless network environment.
  - ☆ SSID is a name to identify a specific network in wireless LAN. If this SSID matches on both devices, communication is possible.
- Do not use where magnetic fields, static electricity or radio interference may occur. If used near the following devices, communication may be interrupted or the speed may decrease. Please use as far as possible.
  - Microwave oven during cooking
  - Bluetooth compatible device
  - Other wireless LAN devices (wireless WEB cameras, PC devices, etc.) except the router (wireless LAN router) that communicates with this air conditioner.
- If the air conditioner is surrounded by a metal object, or if there is an object such as metal or reinforced concrete that cannot pass radio waves between itself and the router, it may not be able to communicate due to the reception of radio noise or a short range.

## Information about Using Wireless LAN

- The air conditioner can be operated from a place that is not directly visible. Therefore, for example, a situation may occur where a person in the room turns ON while another person turns OFF from outside. Especially when infants, children, the elderly, the sick, or the physically handicapped are indoors, use it when a person who can manage it is nearby. In addition, before using, please understand the condition of the room before operating.

- Your smartphone and air conditioner communicate data via our server using the Internet. Therefore, due to the condition of the communication line of your mobile phone company or provider, the setting of your router, or the stop of service due to maintenance of the airCloudHome server, data communication may not be possible, and the system may not or delay operate.
- After connecting the air conditioner to the router, you can perform data communication. To use, you will incur the broadband internet charges and your smartphone network provider charges as per the customer contract.
- If the air conditioner is not operated for a long time or if the home internet network has been completely shut down, it is advisable to initialize the airCloud Home module and reconnect the same.
- Please do not inform other people about the SSID / KEY of this air conditioner.
- Our company guarantees repair of this air conditioner under certain conditions. However, we do not guarantee that stored data is lost or damaged.
- This air conditioner stores network setting information. When disposing of this air conditioner, initialize the built-in airCloud Home module (Refer to page 42 Restore Factory Setting).
- Customers are responsible for resolving any deficiencies in the Internet and wireless environment at home.
- If you operate the air conditioner using the App, some of the set functions may be canceled. Check the web page for details.

## SSID & KEY Label Paste

SSID & KEY label details of Air conditioner's built-in airCloud Home module is pasted here for your reference. Please keep it safe for future requirements during pairing process and please write down the installation location (like living room, bed room, etc.) on the label. The AC type is "2" that is for models with a built-in airCloud Home module.

SSID&KEY label paste position	
SSID:	
KEY:	
TYPE:2	
Installation location:	

## About Software License

The software installed in this air conditioner is composed of multiple independent software modules, and each software module has the copyright of Johnson Controls Air Conditioning (Herein after referred to as “the Company”) and a third party. This air conditioner also contains software modules developed or created by us, but these software and accompanying documents have proprietary rights and intellectual property rights of our company. These are protected by copyright law and other laws.

## Initial Setting of App


### Installation of App

Go to Google Play or the Apple Store (depending on your smartphone) and download the “airCloud Home” Application

- Please read and agree to “the Terms of Use” on the App.
- The App is free. Communication charges will be incurred for download and operation as per the local cell phone provider.
- Android is a trademark and registered by Google LLC.
- iPhone is a trademark and registered by Apple Inc.
- QR code is a trademark and registered by DENSO WAVE Inc.

## Registration on App

- (1) Click “Create Account”.
- (2) Enter your name and click “Continue”.
- (3) Enter your mobile number and password (or click “E-mail” tab, and enter your E-mail address and password), read the “terms and conditions” and check on the box, click “Continue”.
- (4) Enter received verification code you received and click “Continue”.
- (5) Click “Auto-Detect My Location” or Enter address details manually, and click “Finish”.
- (6) The account has been created successfully.



### Note:



The first registered user can manage all the users and set access rights as a group owner. Group owner can invite others to register.

## Air Conditioner Registration and Router Connection

Make sure that the air conditioner is plugged in, then follow the steps below to add your air conditioner device to the App.

- (1) Click “Add Air Conditioner” on the top screen after registration and login your App.
- (2) Scan QR code on the bundled SSID & KEY label in this user manual or by lifting the front panel of your air conditioner.
- (3) If the SSID shown on the App is your home router, enter your home router password, click “Next”. Otherwise, click “Change Wi-Fi Network”, select your home router enter password and click “Next”,

- (4) Switch ON your air conditioner now. Once your air conditioner is switched on, or reset the internal settings (restore the factory settings) by remote control, it will automatically set into pairing mode for 10 minutes. Wi-Fi LED on air conditioner's panel (see diagram in status indicator section) will blink for 3 times repeatedly showing air conditioner is in pairing mode. Wi-Fi LED keeps blinking till communication with Wi-Fi router is succeeded. When the airCloud Home module reset operation is performed through the remote control, the pairing mode can be entered without restarting the air conditioner.
- (5) Click "Change Wi-Fi Network", select the Wi-Fi access point of the Built-in airCloud Home module with SSID printed on the bundled SSID&KEY Label, input password (the KEY). Click right arrow icon on the screen top to continue for connecting your smart phone with the Adapter.
- (6) Waiting for the built-in airCloud Home module to connect to your home router. When communication is established, Wi-Fi LED on panel will be continuously ON after blinking.
- (7) Waiting for the Smartphone to connect with your home network. If your Smartphone is connected to another wireless network then click on Change Wireless Network & select home network.
- (8) Please assign a name to your registered air conditioner. If you assign a custom name to your air conditioner, it will not be compatible with your smart speaker (integrated with Alexa or Google Assistant), so we recommend that you select a name from the pre-defined list.
- (9) Your air conditioner has been successfully configured.





- (1) If communication cannot succeed within 10 minutes, please follow the instructions of the App to complete the pairing process again.
- (2) If a user in the group has already registered some air conditioning units, the other users in the same group can also control the unit.
- (3) If the air conditioning is not configured with router, at power on unit enters into pairing mode every time for 10 minutes with Wi-Fi indication blinking for 3 times.
- (4) If the air conditioning is already configured with router, and router detection is available then at power on, unit will skip the pairing mode & try to connect to router.
- (5) Please enter the SSID name of the air-conditioner to proceed with the pairing process if unable to scan QR code.

# Initialization of the Built-in airCloud Home Module

Reset the internal settings (restore the factory settings) by remote controller. Please note that the configuration will be cleared and pairing procedure will be required to do again to use the built-in airCloud Home module.

- (1) Press Mode key and ON Timer key simultaneously, pointing the remote controller towards the air conditioning unit.
- (2) Make sure Wi-Fi LED on Indoor Unit flashes 4 times repeatedly for about 20 seconds (LED is turning off between 2 sequences of 20 seconds).
- (3) Restart the unit (turn power OFF during 1 minute, then turn power ON again) and check that the Wi-Fi LED is blinking 3 times.

If Wi-Fi LED is indeed flashing 3 times, pairing mode is well activated and factory settings have well been restored.



Indoor Unit Indications: Wi-Fi LED

**Note:**

- Please try to power OFF/ON your air conditioner from mains switch when an error occurs.
- Wi-Fi is a trademark or registered trademark of the “Wi-Fi” Alliance”.

## Information

### Capabilities

#### Heating Capability

- This room air conditioner utilizes a heat pump system that absorbs exterior heat and brings it into a room

**CAUTION**

Do not use a stove or any other high temperature devices in proximity to the indoor unit.



- As the ambient temperature gets lower, heating capability will also lower. In such a situation, the inverter work to increase compressor rpm to keep the unit’s heating capability from decreasing. If the unit’s heating performance is still unsatisfactory, other heating appliances should be used to augment this unit’s performance.
- The air conditioner is designed to heat an entire room so that it may take some time before you feel warm. Timer operation is recommended for effective preheating ahead of the desired time.

#### Cooling and Dehumidifying Capabilities


- If the heat present in a room exceeds the unit’s cooling capacity (for example, if there are many people in the room or other heating appliances are used), the preset room temperature may not be reached.

### Refrigerant Information

- For the refrigerant charge information, please refer to the outdoor unit installation manual or specification label.

## Status Indicator (LED Indicator may light up while the air conditioner is turned off)

Wi-Fi Lamp	Corresponding Status
LED OFF	<ul style="list-style-type: none"> <li>● Pairing time out occurs (after 10 mins.) &amp; configured router not detected.</li> <li>● Air conditioner is not plugged in.</li> <li>● Built-in airCloud Home module and the air conditioner is not connected.</li> </ul>
LED ON	<ul style="list-style-type: none"> <li>● The connection between the Built-in airCloud Home module and the router is completed.</li> <li>● The operation can be conducted through smartphone.</li> </ul>
LED flashes 3 times	Waiting to connect to the Wi-Fi router using AP mode.
LED flashes 4 times	Restoring factory setting procedure has started.
LED flashes 5 times	Communication error between air conditioner & Built-in airCloud Home module (Error detection time: approx 24 mins.)
LED flashes with 4 sec ON/ 1 sec OFF	Router connection error.
LED flashes with 4 sec ON/ 3 sec OFF	Cloud connection error. (Error detection time: approx 30 mins.)



# MAINTENANCE

## ⚠ CAUTION

Cleaning and maintenance must be carried out only by qualified service personnel. Before cleaning, stop operation and switch off the power supply.

### 1. PRE-FILTER

Clean the Pre-filter, as it removes dust inside the room. In case the Pre-filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the Pre-filter following the procedure below.




#### PROCEDURE

- 1 Open the front panel and remove the Pre-filter
  - Gently lift and remove the air purifying filters from the air purifying filter frame.


- 2 Vacuum dust from the Pre-filter and air purifying filter using vacuum cleaner. If there is too much dust, rinse under running tap water and gently brush it with soft bristle brush. Allow filters to dry in shade.



- 3
  - Re-insert the air purifying filter to the filter frame. Set the Pre-filter with "FRONT" mark facing front, and slot them into the original state.
  - After attaching the Pre-filters, push the front panel at three arrow portions as shown in figure and close it.



insert the hook to the hole



#### NOTE:

- Air purifying filter should be cleaned every month or sooner if noticeable loading occurs. When used overtime, it may lose its deodorizing function. For maximum performance, it is recommended to replace it every 1 year depending on application requirements.

## ⚠ CAUTION


- Do not operate the air conditioner without Pre-filter. Dust may enter the air conditioner and fault may occur.

## 2. CLEANING OF FRONT PANEL


- Remove the front panel and wash with clean water. Wash it with a soft sponge. After using neutral detergent, wash thoroughly with clean water.
- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly. If water remains at indicators or signal receiver of indoor unit, it causes trouble.

Method of removing the front panel.

Be sure to hold the front panel with both hands to detach and attach it.




### Removing the Front Panel



- When the front panel is fully opened with both hands, push the right arm to the outside to release it, and while closing the front panel slightly, pull it out forward.

### Attaching the Front Panel



- Move the projections of the left and right arms into the Flanges in the unit and securely insert them into the holes.



### CAUTION

- Never use hot water (above 40°C), benzine, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.






## Regular Inspection

PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONNEL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.

<b>1</b>		Is the earth line disconnected or broken?
<b>2</b>		Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?
<b>3</b>		Is the plug of power line firmly plugged into the socket? (Please ensure no loose contact between them).

## AFTER SALE SERVICE AND WARRANTY

### WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS

CONDITION	CHECK THE FOLLOWING POINTS
 If the remote controller is not transmitting a signal. (Remote controller display is dim or blank.)	<ul style="list-style-type: none"> <li>Do the batteries need replacement?</li> <li>Is the polarity of the inserted batteries correct?</li> </ul>
 When it does not cool well	<ul style="list-style-type: none"> <li>Is the fuse all right?</li> <li>Is the voltage extremely high or low?</li> <li>Is the circuit breaker "ON"?</li> <li>Is the setting of operation mode different from other indoor units?</li> </ul>
 When it does not cool well When it does not heat well	<ul style="list-style-type: none"> <li>Is the pre-filter blocked with dust?</li> <li>Does sunlight fall directly on the outdoor unit?</li> <li>Is the air flow of the outdoor unit obstructed?</li> <li>Are the doors or windows opened, or is there any source of heat in the room?</li> <li>Is the set temperature suitable?</li> <li>Are the air inlets or air outlets of indoor and outdoor units blocked?</li> <li>Is the fan speed "LOW" or "SILENT"?</li> </ul>

## FrostWash Operation

FrostWash Operation does not start	<p>It does not wash when outside temperature is less than about 1 degrees Celsius or more than 43 degrees Celsius.</p> <p>It does not wash when the humidity in the room is about 30% or less or about 70% or more.</p> <p>When "FrostWash" is done by operating a remote controller, it does not wash when the room temperature is less than about 10 degrees Celsius or more than about 32 degrees Celsius.</p> <p>When 60 minutes after the end of "FrostWash", "FrostWash" is not operated for product protection.</p>
Noise occurred during FrostWash operation	<p>It is the sound that the internal machine is inflated and contracted by the temperature change and the fin of the heat exchanger is frozen and thawed</p>
 (Clean Function Lamp) blinks	<p>Repeat for 1 second on and 1 second off for 10 seconds</p> <p>Because "FrostWash" can not work when operating the "FrostWash" with remote controller.</p> <ul style="list-style-type: none"> <li>The air conditioner is operating</li> <li>Outside air temperature, room temperature and room humidity are not suitable for "FrostWash"</li> <li>It has not been over 60 minutes since the end of "FrostWash"</li> </ul> <p>Repeat for 4 seconds on and 1 second off for 15 seconds</p> <p>Because FrostWash has not been done for a long time.</p> <p>→ Operate the remote controller to operate "FrostWash".</p>

## Mold Guard Operation

Mold Guard operation does not start	<p>If the air conditioner operation is stopped after heating operation, Mold Guard will not operate.</p> <p>If the air conditioner has operated in cooling and drying mode, including auto mode, for less than 10 minutes, the Mold Guard operation will not start even if the air conditioner is in off mode.</p> <p>If operation of the air conditioner is stop by OFF Timer or GoodSleep Timer, the Mold Guard will not operate.</p> <p>If ON Timer is set and on time is within about 2 hours, the Mold-Guard will not operate.</p>
During Mold Guard	<p> (Clean Function Lamp) on the indoor unit lights up during Mold Guard operation. If Mold Guard operation stop at middle point, FrostWash and Filter sign indicator will turn off.</p>

Notes	<p>The horizontal deflector remain open. Room temperature or humidity may rise. Depending on situation, Mold Guard will operate with Fan Mode.</p> <p>When there would be the window near indoor unit, the water might condense on the window during Mold Guard. If necessary, to cancel Mold Guard.</p> <p>When after FrostWash operation, the water inside the indoor unit evaporates and depending on the room conditions, may emitted as steam. But this is not a malfunction. If necessary, to cancel Mold-Guard.</p>
-------	--

The OPERATION lamp is flashing	Shows preheating or defrosting operation is underway. As the protective circuit or preheat sensor operates when unit operation is stopped during preheating and then restarted, or when operation mode is switched from cooling to heating, the lamp continues to blink.
Does not reach the temperature setting	Actual room temperature may deviate slightly from the remote controller's temperature setting depending on the number of people in the room, indoor or outdoor conditions.

■ The following phenomena do not indicate unit failure.

During heating, the operation indicator blinks and air blow stops	<p>&lt;Operation start&gt; The unit is preparing to blow warm air. Please wait.</p> <p>&lt;In operation&gt; The outdoor unit is defrosting. Please wait.</p>
Hissing or fizzy sounds	Refrigerant flow noise in the pipe or valve sound generated when flow rate is adjusted.
	Refrigerant flow noise occur during changes of maximum fan speed to lowest speed.
Squeaking noise	Noise generated when the unit expands or contracts due to temperature changes.
Rustling noise	Noise generated with the indoor unit fan's rpm changing such as operation start times.
Clicking noise	Noise of the motorized valve when the unit is switched on.
Perking noise	Noise of the ventilation fan sucking in air present in the drain hose and blowing out dehumidifying water that had accumulated in the condensed water collector. For details, consult your sales agent.
Changing operation noise	Operation noise changes due to power variations according to room temperature changes.
Mist emission	Mist is generated as the air within the room is suddenly cooled by conditioned air.
Steam emitted from the outdoor unit	Water generated during defrosting operation evaporates and steam is emitted.
Odors	Caused as the smells and particles of smoke, food, cosmetics, etc. present in room air become attached the unit and blown off into the room again.
The outdoor unit continues to operate even if operation is stopped.	Defrosting is underway (as the heating operation is stopped, the microcomputer checks frost accumulated in the outdoor unit and instructs the unit to perform automatic defrosting if necessary).

If the unit still fails to operate normally after performing the above inspections, turn the circuit breaker off and contact your sales agent immediately.

**Contact your sales agent immediately if the following phenomena should occur**

- The circuit breaker switches off or the fuse blows frequently.
- The switch operation is not stable.
- Foreign matter or water accidentally enters the unit interior.
- The power cord gets excessively hot or its insulation is torn or stripped.
- TIMER lamp on the indoor unit display blinks. (As the nature of the failure can be identified by the blinking cycle, check the blinking cycle before turning off the circuit breaker.)




**Notes**

- In quiet or stop operation, the following phenomena may occasionally occur, but they are not abnormal for the operation.

- (1) Slight flowing noise of refrigerant in the refrigerating cycle.
- (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.

- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the pre-filter and the evaporator regularly must be cleaned to reduce the odor.

Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.

**Please note:**

On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.

The conditions of the local Power Supply Companies are to be observed.




# CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE

## CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL: RAK-VJ60PHAE

RAK-VJ70PHAE



# MAIN PARTS COMPONENT


## THERMOSTAT (Room Temperature Thermistor)

### Thermostat Specifications

MODEL			RAK-VJ60PHAE, RAK-VJ70PHAE	
THERMOSTAT MODEL			IC	
OPERATION MODE			COOL	HEAT
TEMPERATURE °C (°F)	INDICATION 16	ON	18.3 (64.99)	13.7 (56.61)
		OFF	15.0 (59.00)	16.7 (62.06)
	INDICATION 24	ON	26.3 (79.39)	21.7 (71.01)
		OFF	23.0 (73.40)	24.7 (76.46)
	INDICATION 32	ON	34.3 (93.79)	29.7 (85.41)
		OFF	31.0 (87.80)	32.7 (90.86)

## FAN MOTOR

### Fan Motor Specifications

MODEL	RAK-VJ60PHAE, RAK-VJ70PHAE
POWER SOURCE	DC: 340V
POWER OUTPUT	38W
CONNECTION	 <p>(Control circuit built in)</p>

BLU : BLUE

YEL : YELLOW

BRN : BROWN

WHT : WHITE

GRY : GRAY

ORN : ORANGE

GRN : GREEN

RED : RED

BLK : BLACK


PNK : PINK

VIO : VIOLET

# WIRING DIAGRAM

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE

BLK:BLACK YEL:YELLOW  
 BLU:BLUE GRN:GREEN  
 RED:RED WHT:WHITE  
 GRY:GRAY BRN:BROWN




※1: SOME MODEL DO NOT  
 HAVE THIS FUNCTION

**CAUTION!** TURN OFF THE POWER  
 HIGH SOURCE DURING THE  
 VOLTAGE SERVICE WORK.

WIRING DIAGRAM OF THE PRINTED WIRING BOARD

[Remote controller] RC-AGS1EA0E



**HITACHI**

The remote control interface includes the following features and controls:

- Function Icons:**
  - AB (Auto Off)
  - Soft Dry
  - Invalid
  - Temperature display (°C/°F)
  - Time display (Hr)
  - Heat, Auto, Cool, Dry, Fan, A.Cir (Auto Circulation)
  - ON/OFF
  - AM/PM
  - Auto
- Control Panel:**
  - Mode
  - Fan Speed
  - SleepSense
  - Temp
  - Powerful
  - FrostWash
  - Silent
  - Filter
  - Reset
  - On Timer
  - Smart Eco
  - Up/Down
  - Off Timer
  - LeaveHome
  - Left/Right
  - AQtiV-Ion
  - My Mode
  - Wide Reach


星火原光电科技有限公司

ISSUE DATE: 2021-09-05	MODEL: XHY-W2026/W2027
DRAWN BY: 许仁君	TITLE:
CHECKED BY: 戴福章	Main board
APPROVED BY: 江厚雅	
DRAWING NO:	PCB NO:
REVISION: V1.2	
DISK FILE NAME:	STAGE:
	SHEET: 1 OF 1

# CIRCUIT DIAGRAM

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE


- NOTE 1. The type of capacitors are as follows.
- | Symbol | Type                   |
|--------|------------------------|
| F      | Film Capacitor         |
| E      | Electrolytic Capacitor |
| D      | Electrolytic Capacitor |
2. The symbol of forms show the following.
- | Symbol | Form                   |
|--------|------------------------|
| A      | Avial                  |
| R      | Radial                 |
| H      | Manual Insertion       |
| C      | Chip Surface Mounting  |
| S      | Other Surface Mounting |
3. The symbol of mounting board shows the following.
- | Symbol | Form                  |
|--------|-----------------------|
| M      | Main Board            |
| H      | Humidity Board        |
| S      | Humidity Sensor Board |
4. Refer to the following drawing depending on the mounting Board and form.
- | Mounting Board | Form       | Reference Drawing |
|----------------|------------|-------------------|
| M              | A, R, C, S |                   |
| H              | A, R, C, S |                   |
| S              | H          |                   |
5. A 3216 chip component of J\*\*\* in a board mark diagram mounts N0018690, item # (40) (X00002EJ), CJ800-CJ801 in a board mark diagram mounts N0018692, item # (10) (X00002EJ).



Group	A	B	C	D	E	F	G
Region	FULL	100V	JPN	200V	IND	SEA	EU/ANZEU/ANZ

Resistor	Serial	Resistance	Watt	Temp. Coef.	Mounting	Form	Mounting Board	Form	Reference Drawing	Part. No.	Remarks
R001	510	5%	1/4	A	M	O	O	O	O	62	Coment
R002	1M	5%	1/4	A	M	O	O	O	O	28	
R101	1.5k	5%	1/4	C	M	O	O	O	O	37	3226
R102	1.5k	5%	1/4	C	M	O	O	O	O	73	1608
R103	3.3k	5%	1/10	C	M	O	O	O	O	82	1608
R126	8.2k	1%	1/10	C	M	O	O	O	O	56	1608
R128	5.6k	1%	1/10	C	M	O	O	O	O	54	1608
R129	27k	1%	1/10	C	M	O	O	O	O	62	1608
R131	4.7	5%	1/2	A	M	O	O	O	O	23	
R132	5%	1/10	C	M	O	O	O	O	O	19	MOS
R133	20k	5%	1/10	C	M	O	O	O	O	19	MOS
R141	220k	5%	1	R	M	O	O	O	O	20	201209
R201	4.3k	5%	1/4	C	M	O	O	O	O	48	3216
R202	4.3k	5%	1/4	C	M	O	O	O	O	76	1608
R203	4.7k	5%	1/6	A	M	O	O	O	O	52	
R204	3.3k	5%	1/10	C	M	O	O	O	O	76	1608
R205	402	1%	1/4	C	M	O	O	O	O	38	3216
R206	3.3k	5%	1/10	C	M	O	O	O	O	82	1608
R207	100	5%	1/10	C	M	O	O	O	O	29	
R208	0	1%	1/10	C	M	O	O	O	O	65	1608
R211	200	5%	1/8	C	M	O	O	O	O	52	2125
R221	10k	5%	1/10	C	M	O	O	O	O	80	1608
R222	1k	5%	1/10	C	M	O	O	O	O	72	1608
R223	390	5%	1/10	A	M	O	O	O	O	30	
R224	560	5%	1/4	A	M	O	O	O	O	27	
R209	480	5%	1/4	C	M	O	O	O	O	45	3216
R210	180	5%	1/10	C	M	O	O	O	O	59	1616
R211	820	5%	1/10	C	M	O	O	O	O	70	1608
R212	10k	5%	1/10	C	M	O	O	O	O	70	1608
R213	10k	5%	1/10	C	M	O	O	O	O	70	1608
R214	10k	5%	1/10	C	M	O	O	O	O	70	1608
R215	10k	5%	1/10	C	M	O	O	O	O	70	1608
R216	10k	5%	1/10	C	M	O	O	O	O	70	1608
R217	10k	5%	1/10	C	M	O	O	O	O	70	1608
R218	10k	5%	1/10	C	M	O	O	O	O	70	1608
R219	10k	5%	1/10	C	M	O	O	O	O	70	1608
R220	10k	5%	1/10	C	M	O	O	O	O	70	1608
R221	10k	5%	1/10	C	M	O	O	O	O	70	1608
R222	10k	5%	1/10	C	M	O	O	O	O	70	1608
R223	10k	5%	1/10	C	M	O	O	O	O	70	1608
R224	10k	5%	1/10	C	M	O	O	O	O	70	1608
R225	10k	5%	1/10	C	M	O	O	O	O	70	1608
R226	10k	5%	1/10	C	M	O	O	O	O	70	1608
R227	10k	5%	1/10	C	M	O	O	O	O	70	1608
R228	10k	5%	1/10	C	M	O	O	O	O	70	1608
R229	10k	5%	1/10	C	M	O	O	O	O	70	1608
R230	10k	5%	1/10	C	M	O	O	O	O	70	1608
R231	10k	5%	1/10	C	M	O	O	O	O	70	1608
R232	10k	5%	1/10	C	M	O	O	O	O	70	1608
R233	10k	5%	1/10	C	M	O	O	O	O	70	1608
R234	10k	5%	1/10	C	M	O	O	O	O	70	1608
R235	10k	5%	1/10	C	M	O	O	O	O	70	1608
R236	10k	5%	1/10	C	M	O	O	O	O	70	1608
R237	10k	5%	1/10	C	M	O	O	O	O	70	1608
R238	10k	5%	1/10	C	M	O	O	O	O	70	1608
R239	10k	5%	1/10	C	M	O	O	O	O	70	1608
R240	10k	5%	1/10	C	M	O	O	O	O	70	1608
R241	10k	5%	1/10	C	M	O	O	O	O	70	1608
R242	10k	5%	1/10	C	M	O	O	O	O	70	1608
R243	10k	5%	1/10	C	M	O	O	O	O	70	1608
R244	10k	5%	1/10	C	M	O	O	O	O	70	1608
R245	10k	5%	1/10	C	M	O	O	O	O	70	1608
R246	10k	5%	1/10	C	M	O	O	O	O	70	1608
R247	10k	5%	1/10	C	M	O	O	O	O	70	1608
R248	10k	5%	1/10	C	M	O	O	O	O	70	1608
R249	10k	5%	1/10	C	M	O	O	O	O	70	1608
R250	10k	5%	1/10	C	M	O	O	O	O	70	1608
R251	10k	5%	1/10	C	M	O	O	O	O	70	1608
R252	10k	5%	1/10	C	M	O	O	O	O	70	1608
R253	10k	5%	1/10	C	M	O	O	O	O	70	1608
R254	10k	5%	1/10	C	M	O	O	O	O	70	1608
R255	10k	5%	1/10	C	M	O	O	O	O	70	1608
R256	10k	5%	1/10	C	M	O	O	O	O	70	1608
R257	10k	5%	1/10	C	M	O	O	O	O	70	1608
R258	10k	5%	1/10	C	M	O	O	O	O	70	1608
R259	10k	5%	1/10	C	M	O	O	O	O	70	1608
R260	10k	5%	1/10	C	M	O	O	O	O	70	1608
R261	10k	5%	1/10	C	M	O	O	O	O	70	1608
R262	10k	5%	1/10	C	M	O	O	O	O	70	1608
R263	10k	5%	1/10	C	M	O	O	O	O	70	1608
R264	10k	5%	1/10	C	M	O	O	O	O	70	1608
R265	10k	5%	1/10	C	M	O	O	O	O	70	1608
R266	10k	5%	1/10	C	M	O	O	O	O	70	1608
R267	10k	5%	1/10	C	M	O	O	O	O	70	1608
R268	10k	5%	1/10	C	M	O	O	O	O	70	1608
R269	10k	5%	1/10	C	M	O	O	O	O	70	1608
R270	10k	5%	1/10	C	M	O	O	O	O	70	1608
R271	10k	5%	1/10	C	M	O	O	O	O	70	1608
R272	10k	5%	1/10	C	M	O	O	O	O	70	1608
R273	10k	5%	1/10	C	M	O	O	O	O	70	1608
R274	10k	5%	1/10	C	M	O	O	O	O	70	1608
R275	10k	5%	1/10	C	M	O	O	O	O	70	1608
R276	10k	5%	1/10	C	M	O	O	O	O	70	1608
R277	10k	5%	1/10	C	M	O	O	O	O	70	1608
R278	10k	5%	1/10	C	M	O	O	O	O	70	1608
R279	10k	5%	1/10	C	M	O	O	O	O	70	1608
R280	10k	5%	1/10	C	M	O	O	O	O	70	1608
R281	10k	5%	1/10	C	M	O	O	O	O	70	1608
R282	10k	5%	1/10	C	M	O	O	O	O	70	1608
R283	10k	5%	1/10	C	M	O	O	O	O	70	1608
R284	10k	5%	1/10	C	M	O	O	O	O	70	1608
R285	10k	5%	1/10	C	M	O	O	O	O	70	1608
R286	10k	5%	1/10	C	M	O	O	O	O	70	1608
R287	10k	5%	1/10	C	M	O	O	O	O	70	1608
R288	10k	5%	1/10	C	M	O	O	O	O	70	1608
R289	10k	5%	1/10	C	M	O	O	O	O	70	1608
R290	10k	5%	1/10	C	M	O	O	O	O	70	1608
R291	10k	5%	1/10	C	M	O	O	O	O	70	1608
R292	10k	5%	1/10	C	M	O	O	O	O	70	1608
R293	10k	5%	1/10	C	M	O	O	O	O	70	1608
R294	10k	5%	1/10	C	M	O	O	O	O	70	1608
R295	10k	5%	1/10	C	M	O	O	O	O	70	1608
R296	10k	5%	1/10	C	M	O	O	O	O	70	1608
R297	10k	5%	1/10	C	M	O	O	O	O	70	1608
R298	10k	5%	1/10	C	M	O	O	O	O	70	1608
R299	10k	5%	1/10	C	M	O	O	O	O	70	1608
R300	10k	5%	1/10	C	M	O	O	O	O	70	1608
R301	10k	5%	1/10	C	M	O	O	O	O	70	1608
R302	10k	5%	1/10	C	M	O	O	O	O	70	1608
R303	10k	5%	1/10	C	M	O	O	O	O	70	1608
R304	10k	5%	1/10	C	M	O	O	O	O	70	1608
R305	10k	5%	1/10	C	M	O	O	O	O	70	1608
R306	10k	5%	1/10	C	M	O	O	O	O	70	1608
R307	10k	5%	1/10	C	M	O	O	O	O	70	1608
R308	10k	5%	1/10	C	M	O	O	O	O	70	1608
R309	10k	5%	1/10	C	M	O	O	O	O	70	1608
R310	10k	5%	1/10	C	M	O	O	O	O	70	1608
R311	10k	5%	1/10	C	M	O	O	O	O	70	1608
R312	10k	5%	1/10	C	M	O	O	O	O	70	1608
R313	10k	5%	1/10	C	M	O	O	O	O	70	1608
R314	10k	5%	1/10	C	M	O	O	O	O	70	1608
R315	10k	5%	1/10	C	M	O	O	O	O	70	1608
R316	10k	5%	1/10	C	M	O	O	O	O	70	1608
R317	10k	5%	1/10	C	M	O	O	O	O	70	1608
R318	10k	5%	1/10	C	M	O	O	O	O	70	1608
R319	10k	5%	1/10	C	M	O	O	O	O	70	1608
R320	10k										

**BLOCK DIAGRAM**  
 MODEL RAK-VJ60PHAE, RAK-VJ70PHAE




# BASIC MODE

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE

Operation mode	Fan	Cooling	Dry	Heating	Auto	
Basic operation of start/stop button						
Timer functions	Off-timer					
	On-timer					
	Off -> On On -> Off timer					
Fan speed mode (indoor fan)	Auto	<p>Changes from "Hi" to "Med" or "Lo" depending on room temperature.</p> <ol style="list-style-type: none"> <li>Runs at "Hi" until room temperature reaches to "setting temperature-SFTDSC" after operation is started.</li> <li>Runs at "ultra-Lo" when thermo is off.</li> </ol>		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF.(When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p> <p>In modes other than left</p>	<p>Operating mode is judged by room temperature.</p> <p>(1) Judging by room temperature</p> <ul style="list-style-type: none"> <li>Operating mode at start up is judged (initial judgment).</li> <li>(a) Conditions for judgment (any of the followings). <ul style="list-style-type: none"> <li>When auto operation is started after the previous auto mode operation.</li> <li>When auto operation is started after the previous manual mode operation.</li> <li>When the operating mode is switched to auto while operating at manual mode.</li> </ul> </li> <li>(b) Judging method <ul style="list-style-type: none"> <li>[ Cooling ] : Room temperature <math>\geq</math> Remote controller setting</li> <li>[ Heating ] : Room temperature <math>&lt;</math> Remote controller setting</li> </ul> </li> </ul> <p>(2) Judging operating mode change during operation (Continuous judgment).</p> <p>(a) Conditions for judgment</p> <ul style="list-style-type: none"> <li>The mode is reviewed at interval time.</li> <li>*Interval time as below <ul style="list-style-type: none"> <li>The first interval time : 10 minutes</li> <li>The second interval time : 15 minutes</li> <li>On and after the third interval time : 55 minutes</li> </ul> </li> <li>(b) Judging method <ul style="list-style-type: none"> <li>Judge by setting the hysteresis on the final preset temperature.</li> <li>The final preset temperature is the actually targeted preset temperature which is sum of basic preset temperature and each type of shift value.</li> <li>(e.g. preset temperature correction value, powerful shift value, eco shift value, eco sleep shift value, etc.)</li> </ul> </li> </ul> <p>[ Currently cooling ]</p> <ul style="list-style-type: none"> <li>Room temperature <math>\leq</math> Final preset temperature <math>-3^{\circ}\text{C}</math> Change to heating</li> <li>Room temperature <math>&gt;</math> Final preset temperature <math>-3^{\circ}\text{C}</math> Continue cooling</li> </ul> <p>[ Currently heating ]</p> <ul style="list-style-type: none"> <li>Room temperature <math>\geq</math> Final preset temperature <math>+2^{\circ}\text{C}</math> Change to cooling</li> <li>Room temperature <math>&lt;</math> Final preset temperature <math>+2^{\circ}\text{C}</math> Continue heating</li> </ul>	
	Super Hi	Operates at "Super Hi" regardless of the room temperature.	Set to "ultra-Hi" when the compressor runs at cold dash mode speed, and to "Super Hi" in other modes. Runs at "ultra-Lo" when thermo is off.		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "Super Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF.(When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p> <p>Set to "ultra-Hi" when the compressor is running at maximum speed during hot dash or when recovered from defrosting.</p>	
	Hi	Operates at "Hi" regardless of the room temperature.	Set to "ultra-Hi" when the compressor runs at cold dash mode speed, and to "Hi" in other modes. Runs at "ultra-Lo" when thermo is off.		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF.(When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p>	
	Med	Operates at "Med" regardless of the room temperature.	Operates at "Med" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF.(When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p>	
	Lo	Operates at "Lo" regardless of the room temperature.	Operates at "Lo" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.	Set to "Lo" in modes other than when the compressor stops.	<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF.(When reach at "DNZKON", fan speed set to "ultra-Lo" again.) The fan speed is controlled by the heat exchanger temperature; the overload control is executed as in the following diagram:</p>	
	Silent	Operates at "Silent" regardless of the room temperature.	Operates at "Silent" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.	Set to "Silent" in modes other than when the compressor stops.		
Basic operation of temperature controller	Performs only fan operation at the set speed regardless of the room temperature.	See page 29.	See page 31.	See page 33.		


## Basic Cooling Operation




### Notes:

- (1) Condition for entering into Cool Dashed mode. When fan set to "Hi" or "Auto and when the compressor speed (P section) due to temperature difference between setting temperature (including the correction shift only) and room temperature is CMAX or higher.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature  $-3^{\circ}\text{C}$  (thermo off) and iii) when room temperature has achieved setting temperature  $-\text{sftdsc}$  then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value)  $-3^{\circ}\text{C}$ . After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than  $30^{\circ}\text{C}$ . No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to "Hi", compressor rpm will be limited to CSTD.
- (7) When fan is set to "Med", compressor rpm will be limited to CJKMAX.
- (8) When fan is set to "Lo", compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature  $-\text{sftdsc\_8U}$  compressor rpm is actual rpm x 70%.

## Cooling Defrost




## Cooling Powerful Operation



**Notes :**

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTC 2°C.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (5) If the GoodSleep timer is set during powerful operation, the powerful operation will be canceled.
- (6) When the powerful operation is set, the fan speed will be set to "Super Hi" and the compressor's maximum speed will be set to CMAX2 during powerful operation. The compressor's lower limit speed is CKYMIN\_PW.
- (7) The fan speed increases by FNUPPW\_C.
- (8) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


# Dry



**Notes:**

- (1) If the room temperature is (cooling preset temperature) - (1.33°C) or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) - (2°C).
- (2) The indoor fan is operated in the "Lo" mode. During thermo OFF indoor fan will be OFF for 5 minutes and ON for 1 minute.
- (3) When the operation is started by the thermostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
- (4) The compressor is operated forcedly for 3 minutes after operation is started.
- (5) The minimum ON time and OFF time of the compressor are 3 minutes.


## Dry Powerful Operation



### Notes :

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTSD.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (5) If the GoodSleep Timer is set during powerful operation, the powerful operation will be canceled.
- (6) If the differential (the room temperature - the temperature setting) is "the differential  $\geq 3^{\circ}\text{C}$ " after powerful setting, the compressor's maximum speed during powerful operation will be set to SDMAX. Then the differential reduce "the differential  $\leq 233^{\circ}\text{C}$ " during powerful operation, the compressor's speed will be set to SDRPM.  
If the differential (the room temperature - the temperature setting) is "the differential  $< 3^{\circ}\text{C}$ " after powerful setting, the compressor's minimum speed during powerful operation will be set to SDRPM.
- (7) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


## Basic Heating Operation



**Notes:**

- (1) Condition for entering into hot dashed mode. When fan set to "Hi" or "Auto" and i) room temperature is 18 or less, and ii) outdoor temperature is 10 or less, and iii) compressor speed (P section) due to temperature difference between setting temperature(including shift value only) and room temperature is WMAX or more.
- (2) The maximum compressor speed period during hot dash is finished when i) room temperature has reached the setting temperature + SFTDSW. ii) thermo off.
- (3) During hot dashed operation, thermo off temperature is setting temperature (with shift value) +3 . After thermo off, operation continue inn Fuzzy control mode.
- (4) Minimum "ON" time and minimum "OFF" time of compressor operation is 3 minutes.
- (5) During normal heating mode, compressor maximum rpm WMAX will maintain for 120 minutes. No time limit constrain if room temperature is 18 or less and outdoor temperature is 2 or less.
- (6) During preheating or defrosting or auto fresh defrosting mode, indoor unit operation lamp will blink.
- (7) When heating mode starts, it will enter into preheating mode if indoor heat exchanger temperature is less than YNEOF + 0.33 .
- (8) When fan is set to "Med" or "Lo" or "Silent", compressor rpm will be limited to "WJKMAX" or "WBEMAX" or "WSZMAX".
- (9) During "Ultra-Lo" mode, if room temperature is 18 or less, indoor fan will stop. If room temperature is 18 + 0.33 or more, fan will continue in "Ultra-Lo" mode. However, "Ulrrta-Lo" mode during preheating or preheating after defrosting does not stop if room temperature is 18 or less.
- (10) During hot dashed or outdoor temperature is -5 or less, compressor rpm is WMAX2.
- (11) During hot dashed, when room temperature reaches setting temperature + SFTDSW compressor rpm is actual rpm x DWNRATEW.

## Setting Defrosting Inhibit Period




### Notes:

- (1) The first inhibit time after operation start is set to DFTIM\_FST.
- (2) From the second time onwards, the inhibit time is set according to the time required for defrosting.

Reverse cycle operation time  $\geq$  [DEFCOL] : DEFTIM\_COL is set.

Reverse cycle operation time  $<$  [DEFCOL] : The time corresponding to outdoor temperature is set.


## Heating Powerful Operation



### Notes :

- (1) Pressing the "POWERFUL" button will increase the temperature setting by PWSFTW.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Defrost is inhibited for 20 minutes after the start of the powerful operation.
- (5) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (6) If the GoodSleep timer is set during powerful operation, the powerful operation will be canceled.
- (7) When the powerful operation is set, the fan speed will be set to "HIGH" and the compressor's maximum speed will be set to WMAX2 during powerful operation. The compressor's lower limit speed is WKYMIN\_PW.
- (8) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.



## Leave Home




### Notes:

Perform Leave Home operation according to the following control contents.







- (1) Operation mode : Heating
- (2) Temperature set : 10°C ~ 16°C
- (3) Temperature setting correction shift : + 『SFTLVHM』
- (4) Indoor fan : 『FWH\_P』
- (5) Outdoor fan speed :
- (6) Compressor start control : } Same as Basic Heating operation
- (7) Compressor speed :
- (8) Lamp indication : i ) Operation lamp : ON  
ii ) Timer lamp : OFF( Cotinuous operation ) ; ON( Day timer operation )



# Frost wash



- (1)The total hours of air conditioning operation is more than 42 hours(SLEEP、ON TIMER operation will take 84 hours), And air conditioner is operated for more than 30 minutes, Meanwhile, the outdoor temperature and indoor humidity are suitable for the Frost Wash(Area A、B in Fig.3、4),Frost Wash (auto) start;
  - (2)Within 2 hours before the ON TIMER designated time,Frost wash(auto) cannot be operate;
  - (3)ONCE TIMER (ON/OFF TIMER) operation cannot be set,when Frost wash(auto) is running;
  - (4)When the Frost Wash is stopped during Frost Wash operation, the unit automatically restart Frost Wash at the next operation stop.
  - (5)Before the Frost period start,the outdoor temperature $\geq 16^{\circ}\text{C}$ . Or before the defrosting period finish,the heat exchanger temperature  $\geq 0^{\circ}\text{C}$ . The Heating period will not running. Fan period 1~ Fan period 2 all turn to Fan operation
  - (6)In frost period,The maximum time is 10 minutes after the heat exchanger temperature  $\leq -10^{\circ}\text{C}$
  - (7)Heating period will finish after the heat exchanger temperature  $\geq 35^{\circ}\text{C}$ ,remanent time turn to Fan period 2,the total time unchanged
  - (8)Fan period 1~ Fan period 2 will not running,when last operation was HEATING;
  - (9)When device operat Frost wash during ON condition,the device will stop and have blance time(3 minutes)
  - (10)Before the Frost period start,OH temperature $\geq 60^{\circ}\text{C}$ ,Original blance period time will add 3 minutes
- ※1 According to room humidity, the Frost period time becomes as it is shown in Fig.1.  
 ※2 According to Compressor rotation speed, the Outdoor fan becomes as it is shown in Fig.2.  
 ※3 The Compressor rotation speed becomes as it is shown in Fig.5.about area A,  
 The Compressor rotation speed becomes as it is shown in Fig.6.about area B




# REFRIGERATING CYCLE DIAGRAM

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE


COOLING, DEHUMIDIFYING, DEFROSTING

Refrigerant flow  $\longrightarrow$



HEATING

Refrigerant flow  $\dashrightarrow$



# Procedure for Disassembly and Reassembly

INDOOR UNIT RAK-VJ60PHAE, RAK-VJ70PHAE

## 1. Front Panel

Be sure to hold the front panel with both hands to detach and attach it.




Fig. 1

1. Push the end of the right-side arm outward to release the tab.
2. Move the left-side arm outward to release the left tab, and then pull the panel towards you.

## 2. Front cover

- (1) After removing the screw of fixing the terminal cover, hold the handle of terminal cover and remove it.
- (2) After removing two screws, pull the center of the front cover forward and release the claws
- (3) Hold the front cover at both lower sides and pull them forward to remove.




Fig. 2

## 3. Control P.W.B. and Indicating P.W.B.

- (1) Remove each connector from the lead wire.
- (2) Remove the four P.W.B. supports from the control P.W.B.

- (3) Pull the support hook at the upper side of the indication lamp of the indicating P.W.B. and pull out the P.W.B. forward.




Fig. 3

## 4. Tangential air flow fan and fan motor

- (1) Loosen the fan lock screw.




Fig. 4

- (2) Press the fan motor cover 2 fixed pawl, and remove from the right to.




Fig. 5

(3) Pull fan motor out of the remove the right.




Fig. 6

- (4) Remove the screws from the upper and lower bearing covers.
- (5) Remove the locking hook of the lower bearing cover from the Cabinet.




Fig. 7

(6) Remove the fan and bearing from the left.




Fig. 8

**Points for attention of fan motor and tangential air flow fan installation.**

When installing the flow fan, the first part of the fan and water seal plate on the tube plate overlap, then tighten the screw.




Fig. 9

**5. Stepping motor**

(1) The FC-guide frame fixed claw right side press. Remove the FC-guide from the rear.




Fig. 10

(2) Remove the stepping motor screws and take off the stepping motor.




Fig. 11

# DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE

## 1. Control power circuit




Fig. 1-1

- An AC power supply from indoor unit passes through the 3.15A fuse, varistor (VA001), and noise filter circuit and rectified and smoothed by DB1 and C003 to become a DC current 325 V. It is then supplied to indoor fan motor drive circuit, and switching power circuit.
- The switching power circuit, as controlled by IC001, drives the primary winding of the transformer (T001) to produce a specified voltage at the output winding. [The output terminal (pin ⑤) of IC001 has a switching voltage. But it changes in voltage peak and oscillation period depending on the power load. usually, the oscillation frequency when the air condition operation is about 64.5 kHz. In the standby state, the oscillation frequency is lowered to a level as low as 64.5 kHz or so to reduce the standby power.]
- The outputs of the output windings of the transformer is rectified and smoothed to become DC voltages at primary 18.5 V, 12 V, and 8.5 V respectively. The primary 18.5 V is supplied to the drive circuit of the indoor fan motor, the 12 V is supplied to each vane motor and to the drive circuits of the cleaning unit driving motor and other equipment, and the 8.5 V is adjusted to a stable 5 V by IC101 and supplied to the microcomputer peripheral circuit.

### Check

If a failure in a part or circuit has produced an abnormal current in the power supply, the 3.15A fuse will melt down to prevent further damage. If the 3.15A fuse melts down, check the indoor fan motor, switching electrical circuit, and other components and replace any defective part.

### Check

If an abnormally high voltage is applied to the power supply, the 3.15A fuse and varistor (VA001) will prevent further damage. If a high voltage results in the 3.15A fuse melted down, the varistor (VA001) should have deteriorated and destroyed. Therefore replace it at the same time.

### Caution

The primary circuit of the transformer (T001) has a voltage to ground. Guard against electric shocks.

## 2 . Stepping motor drive circuit




Fig. 12-1

[Connector circuit waveform while the motor runs]

Voltage waveforms of different phases as viewed from the OV line while the motor rotor is turning counterclockwise as viewed from the shaft side




Fig. 12-2

- Each stepping motor runs as excited in 1 or 2 phases at 100 PPS or 200 PPS.
- The excitation pattern passes the microcomputer (IC601) and then the driver IC and excites the coil of each stepping motor.
- Some models not need to install the horizontal sweep motor.

### 3. Drive circuit of the indoor fan motor





Fig. 3-1

< The circuit check (For test) >

Name	Test point	Test voltage
Motor drive power	CN2 ① pin- ④ pin	About 325V
Motor control power	CN2 ⑤ pin- ④ pin	About 15V
Motor speed signal	CN2 ⑥ pin- ④ pin	About 2-6V
Motor rotation speed debug	CN2 ⑦ pin- ④ pin	About 7.5V

< Pin 6 - Pin 4 voltage one example >



\* The voltage above is all motor operation vol. when you start the test, take care of your connector, do not touch the different pin together.  
\* The voltage of pin ⑥ - pin ④, pin ⑦ - ④ maybe different from above.

< Typical circuit waveform >




Fig. 3-2

- The indoor fan motor receives VDC (motor drive power supply), VCC (power supply for the control circuit inside the motor), and VS (speed command voltage) from CN2. The indoor fan motor returns an FG signal of a frequency that matches the rotation speed.
- VCC stabilizes the primary 18.5V power supply into 15V by using Q201 and supplies it.
- While on standby for a remote control signal, the Q201 shuts down the VCC and reduces the standby power.
- The VS receives a command voltage from the microcomputer. The VS terminal undergoes an analog voltage that matches the Lo level time ratio of the pulse signal from pin ⑥⑨ of the microcomputer. (See Fig. 3-2.)
- The FG terminal undergoes a signal of 12 pulses per revolution of the motor shaft. By counting the pulse rate, the microcomputer recognizes the motor speed, thereby performing feedback control.

**Caution**

The indoor fan motor and drive circuit are connected to the primary power supply. They therefore have voltage to ground. Guard against electric shocks.

**Caution**

While the product is energized, do not under any circumstances detach or reattach a connector. Any such practice would cause a high voltage to run, resulting in the indoor fan motor and board circuit being destroyed. (Check the discharge of the C003 before detaching or reattaching the connectors.)

#### 4. Buzzer Circuit




Fig.4-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin (32) of the micro computer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.




Fig.4-2 Buzzer Operation

#### 5. Remote control reception circuit




Fig.5-1

[Typical communication waveform]





Fig. 5-2


- An infrared signal from the remote control unit is converted to an electrical signal by the remote control light-receiving unit and is received by the microcomputer. Data is transmitted as digital data 0 and 1 by changing the interval of the basic pulses at about 420 μs.

## 6. Initial Setting Circuit (IC531)

- When power is supplied, the microcomputer reads the data in IC531 (E<sup>2</sup>PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC531; data will not be erased even when power is turned off.



## 7. Temporary Switch Circuit





- The temporary switch is used to operate the air conditioner temporarily when the wireless remote control is lost or faulty.
- The air conditioner operates in the automatic mode by pressing the temporary switch. If the power switch is set to OFF then ON it also operates in the automatic mode when the temporary switch is pressed.

## 8. Room Temperature Thermistor Circuit

A room temperature thermistor circuit is shown in Fig. 8-1.

According to room temperature, the voltage of point (A) becomes as it is shown in Fig.8-2.



## 9. Heat Exchanger Thermistor Circuit

Heat exchanger temperature is noticed inside the room

- (1) Preheating
- (2) Low-temperature defrosts at cooling and dehumidification operation time.
- (3) Not working of reversing valve or detection of opening of heat exchanger thermistor is controlled.
- (4) The microcomputer will estimated the pressure of the compressor due to the intermediate temperature of the IDU heat exchanger.

When reach the set pressure value of the microcomputer, the compressor speed will be adjusted to protect the compressor pressure.

According to heat exchanger temperature, the voltage of point A becomes as it is shown in Fig. 9-2.




Fig. 9-1





Fig. 9-2

## 10. Humidity sensor circuit



The resistance value of the humidity sensor is adjusted according to the change of ambient humidity.

With the change of resistance value, the voltage also changes, and the microcomputer will read the voltage signal.

# 11. Indoor/outdoor communication circuits




Fig. 11 -1





Fig. 11 -2

- Indoor and outdoor communications are conducted by using lines 2 and 3 of F cable. Line 2 of F cable is shared with a transmission channel that powers the outdoor unit.
- Data communicated between the indoor and outdoor units are outputted from the microcomputer as serial signals and are transmitted as demodulated by a 30 kHz carrier wave. (Both the indoor and outdoor microcomputers directly output a signal demodulated at 30 kHz.)

**Check**

If a cable poorly inserted in the indoor terminal board or some other failure overheats the terminal board and the temperature fuse of the terminal board blows out, the power to the indoor communication circuit will be shut down to stop the communications function.

**Check**

If communication fails between the indoor and outdoor units for some reason, the product will give a self-diagnosis display either by "the timer lamp blinking 3 times" or "the timer lamp blinking 12 times" depending on the cause.

## SERVICE CALL Q & A

MODEL RAK-VJ60PHAE, RAK-VJ70PHAE

### Cooling operation

**Q1** The compressor sometimes stops during cooling.



**A1** Check if the heat exchanger of the indoor unit is covered with frost. Wait for 3 to 4 minutes until the frost disappears.

Cooling when the room temperature is low may cause the heat exchanger of the indoor unit to gather frost.

### Dehumidification

**Q1** The indoor unit produces a noise that goes "shaaahhh" during dehumidification.



**A1** That is a noise produced by refrigerant flowing through the pipe.

**Q2** Cold air comes out during a dehumidifying operation.



**A2** To improve the dehumidification efficiency performs quiet fan operation. Therefore the air is cold and it is not a malfunction.

**Q3** The operation does not stop even by setting the temperature higher than room temperature on the remote controller.



**A3** It sets to perform dehumidifying operation by setting the temperature slightly lower than remote controller setting.

### Heating operation

**Q1** The product sometimes fails to produce a wind during heating.



**A1** Defrosting is in progress. Wait 5 to 10 minutes until the frost on the outdoor unit disappears.

**Q2** The product begins with a slight fan speed during heating even though set to "Hi fan" or "Med fan" or "Low fan" or "silent fan".



**A2** At the first of the heating, the product will run for 30 seconds with a slight fan speed. When set to strong fan speed, the product will begin with a slight fan speed operation, producing a weak fan speed for 30 seconds, and then switch to strong fan speed.

**Q3** The product stops during heating even though it is set to "30°C."



**A3** When heating is conducted despite the high outdoor temperature, the product may stop to protect its equipment.

### Auto-fresh defrost

**Q1** During heating, I turned off the product by using the START/STOP button. But the "operation lamp" is blinking and the outdoor unit is running.



**A1** The "auto-fresh defrost" should be working. When stopped, the product will check its outdoor unit for frost and, if there is any frost, conduct defrosting and then stop operating.

### Automatic operation

**Q1** During an automatic run, switching the fan speed selector will not change the fan speed.



**A1** The product will switch automatically to automatic fan speed. You cannot select strong or weak fan speed by remote control but you can select fan speed and quiet.

**Q2** How is the automatic operation mode determined?



**A2** According to the room temperature, heating or cooling operation is automatically selected. Refer to the basic operation section.

## Common, etc.

**Q1** In "automatic fan speed" mode, the indoor fan changes from strong fan speed to weak fan speed to slight fan speed.



**A1** This does not abnormal. It is because the cold fan speed prevention is working.

In fan speed "automatic" mode, the product will sense the heat exchange temperature and, when the temperature goes down, the product will automatically switch to strong wind to weak fan speed to slight fan speed.

**Q2** At operation startup, the outdoor unit becomes noisy.



**A2** At operation startup, the product will set the rotation speed of the compressor to full power and increase its heating and cooling capacity, resulting in a slightly higher noise level. This is not a sign of a breakdown.

**Q3** The outdoor unit sometimes changes in its noise.



**A3** The difference between the thermometer temperature setting and room temperature will change the rotation speed of the compressor. This is not a sign of a breakdown.

**Q4** There is a difference between the temperature setting and room temperature in room temperature control.



**A4** The room structure, air stream, or other factor may cause a gap between the room temperature setting and actual room temperature. If there is any difference between the setting and the room temperature, adjust the temperature setting to match the living space to a comfortable temperature.

**Q5** The product will not produce wind right after startup.



**A5** After turning ON the power switch or breaker, setting the product to heating or dehumidification will activate a preliminary operation for 1 minute. At that time, heating will cause the operation lamp to blink. This is not a sign of a breakdown.

**Q6** I performed internal cleaning, but didn't succeed in controlling the mold in the room.



**A6** Internal cleaning will clean the inside of the indoor unit of the air-conditioner, thereby controlling mold generation. This will not control the mold in the room.


## Wireless remote control

**Q1** I tried to change the setting with the "room temperature" button of the remote control unit in vain.




**A1** You cannot make this setting when the product is in "air purification" mode. Moreover, you cannot set the product to a desired setting when quick laundry or dew control is being performed with the "auto" or "quick dehumidification" button.

## STRUCTURE OF AN INDOOR UNIT ELECTRIC PARTS



### Removing electrical parts

1. Remove the electrical parts cover.
2. Remove the connectors from the CN2, CN4, CN7A, CN12, CN16, CN17.



### Removing control P.W.B.

1. Remove all the connectors from the control P.W.B.
2. Remove the P.W.B. from the P.W.B. support.

### Removing the indicating P.W.B.

1. Remove the connector from the CN16 on the control P.W.B.
2. Remove the upper hook from the indicating P.W.B. lock resin, pull the P.W.B. forward a little and remove it.


## Other instructions

### (1) Detaching and reattaching the receptacles for tab terminal

All the receptacles for connecting tab terminals are with a locking mechanism. Forcibly pulling any such receptacle without unlocking it will destroy it. Be on guard.


When reconnecting it, insert it securely all the way home.

#### · Receptacle types and how to unlock them



Vertical (with a resin case)

Hold the resin case and pull it out.




Horizontal (with a mild resin cover)

Hold the cancel button down on the mild resin cover while pulling it out.

### (2) Detaching and reattaching the board connector

The product comes equipped with many board connectors provided with lock mechanism. Forcibly pulling any such part without unlocking it will destroy it. Be on guard. When reconnecting it, insert it securely all the way home.

Pinch the locking mechanism with your fingers and pull it out unlocked.



### (3) Do not detach or reattach the connectors while energized

Do not under any circumstances detach or reattach the connectors while energized. That would destroy the board components and fan motor. For both the indoor and outdoor boards, ensure that the smoothing capacitor has discharged its electricity fully before you do your work.

## Troubleshooting support

No	Function	Description
1	Self-diagnosis display [Display on the indoor unit side]	<ul style="list-style-type: none"> <li>· The failure mode detected on the indoor unit side is displayed by blinking the "timer lamp". And a failure detected on the outdoor unit side will be indicated by the "time lamp" blinking 4 times.</li> <li>· If the outdoor unit side detects a failure, the product will first conduct several operation retrials. There are some failure modes with no lamp display while retrials are continued.</li> </ul> <p>[Failure mode where retrials are continued and the indoor unit lamp does not end up giving a display]</p> <ul style="list-style-type: none"> <li>OH thermistor heat-up</li> <li>Overload lower limit cut</li> <li>Low-frequency things</li> </ul>
	[Buzzer on the indoor unit side]	<ul style="list-style-type: none"> <li>· The failure codes both indoor unit and outdoor unit can be alerted by buzzer.</li> </ul>
	[Display on the outdoor unit side]	<ul style="list-style-type: none"> <li>· The failure mode detected on the outdoor unit side is displayed by blinking the "LD301". Detecting a failure will stop the outdoor unit and keep blinking the LD301 until it is restarted. (The communication error will persist until the communication is reestablished.)</li> </ul>
2	Self-diagnosis memory	<ul style="list-style-type: none"> <li>· The failure modes detected on the indoor and outdoor unit sides are stored in the nonvolatile memory of the indoor unit and can be read later on. (The memory will remain even after power-off.)</li> <li>· The failure modes detected on the outdoor unit side are written in memory every time any such mode occurs. The failure mode can therefore be detected on the indoor unit side without waiting for the retry frequency to reach the display of the indoor unit lamp. Moreover, the normal self-diagnosis display function which rarely occurs will store and display failure modes that do not end up displaying the indoor unit lamp. (Any such mode may be unable to be stored if indoor or outdoor communications is in a failure.)</li> <li>· The product stores 5 last-stored failure modes.</li> <li>· There is a function for deleting memory. Once you clear the memory and run the product for several days, you can read the failure modes and check them, thereby detecting the less frequent failure phenomena.</li> <li>· Failure modes can be checked by both the blinking of the lamp of the indoor unit and the sound of the buzzer</li> </ul>

※The "self-diagnosis function of the communication circuit" available in our conventional models is now incorporated as part of the normal self-diagnosis function. In the case of a failure in the communication circuit, you do not have to conduct a special operation and the operations can be automatically divided into 3 blinking operations and 12 blinking operations of the timer lamp. However, a strong external noise may have resulted in 12 times of blinking.

**TROUBLESHOOTING WHEN TIMER LAMP BLINKS.**

Perform troubleshooting according to the number of times the indoor timer lamp and outdoor blink.

**1. How to count the lamp blinking frequency**

- The product will repeat blinking with 2-second intermissions.
- The blinking speed is as follows: on for 0.35 seconds and off for 0.35 seconds.



2. If you wish to try another operation while the lamp is blinking, operate the OFF/ON button on the remote control unit. The first push will reset the indoor microcomputer, while the second will activate the product (except for the mode in ※1).

**SELF-DIAGNOSIS LIGHTING MODE**

Refer to the table below if the timer indicator (orange) is blinking.

No.	Blinking of Timer lamp	Reason for indication	Possible cause
1	once	<u>Refrigerant cycle defective</u>	Refrigerant cycle defective
2	2 times	<u>Outdoor unit forced operation</u> When the outdoor unit is in forced operation or balancing operation after forced operation	Electrical parts in the outdoor unit
3	3 times	<u>Indoor interface defective</u>	Indoor interface circuit
4	4 times	<u>Outdoor electrical assembly defective.</u>	Please check at the outdoor electrical led lamp blinking (LD301) and refer to self diagnosis lighting mode for outdoor unit.
5	9 times	<u>Room thermistor or heat exchanger thermistor or humidity sensor is faulty.</u> When room thermistor or heat exchanger thermistor or humidity sensor is opened circuit or short circuit.	(1) Room thermistor (2) Heat exchanger thermistor (3) Humidity sensor
6	10 times	<u>Over-current detection at the DC fan motor</u> when over-current is detected at the DC fan motor of the indoor unit.	(1) Indoor fan locked (2) Indoor fan motor (3) Indoor control P.W.B.
7	12 times	<u>Outdoor interface defective</u> When the interface signal from the outdoor unit is interrupted.	Outdoor interface circuit
※1 8	13 times	<u>IC531 data reading error</u> When data read from IC531 is incorrect.	IC531 abnormal
9	21 times	<u>Outdoor communication error</u> Communication failure due to other home appliances	(1) Connecting cable check (2) Removal of noise cause (3) Connection cable is reverse
※2 10	25 times	CN7A & CN7B connected with both RAC, wifi or H-link	Please don't connect same external device CN7A & CN7B

( -- Lights for 0.35 sec. at interval of 0.35 sec..)

※2 THE LAMP WILL BLINK ONLY WHEN 25 TIMES FAILURE IS CALLED OUT BY HHRC.

All indicator lights are blinking. ※ Buzzer will be sounded at the same time as the installation first blinks.			
Flashing lamp	Blinking times	Checkpoint	Treatment and replacement parts
All lamps	1	Abnormal power supply	If 100V is applied to the 200V model, it is not a failure. Please repair the power supply.
	2	Connecting cable connection failure	Insufficient insertion of terminal block inside and outside. Confirmation of reverse connection.
	3	Forget to open the service valve	Check if the service valve is open.

REFER TO THE BELOW TABLE IF THE INDOOR UNIT DOSE NOT WORK AT ALL.

Fix CN2 connector	Action/replacement parts,etc.
FU1 (3.15A) fuse blown	Replace the part which caused blowing/disconnection of FU1 fuse.
Come off or disconnection of the connector for indicating P.W.B	Fix CN16 connector
Failure of control P.W.B	Refer to the service guide for how to determine the failed part

**<Cautions>**

- (1) If the interface circuit is faulty when power is supplied, the self-diagnosis display will not be displayed.
- (2) If the indoor unit does not operate at all, check to see if the connecting cable is connected or disconnected.

## SELF-DIAGNOSIS MEMORY FUNCTION

Failure modes are stored in the nonvolatile memory of indoor unit and shall be redisplayed by remote controller.

This function is useful in checking the failure modes either during switching OFF the power or restarting the device without checking the number of indication lamp blinking . Remote controller can redisplay up to last 5 failure modes from the memory. However, failure modes which are rarely to occur are also stored in the memory which caused the numbers of failure more than 5. Thus, for some failure modes which are unable to retrieve because of remote controller limit to redisplay only 5 failure modes, it can be found by clearing up the memory first then recheck the memory content again during the visit at the customer place.

## ERROR CODE INFORMATION

### <HOW TO DISPLAY ERROR CODE >

1. Press three key ( [On Timer] + [Fan Speed] + [Reset] ) button on the remote control for 5 seconds to avoid access by User.

2. Press “” (Temperature) button of the remote control and select the “7J” option.

3. Press “” (Fan Speed) button of the remote control, then Press “” (Temperature) button select the “t0” option.

4. Press “” (Fan Speed) button of the remote control, then Press “” (Temperature) button select the “01” option.

5. Press “” (On/Off) button of the remote control, the fault information will be seen.

Function Name	Value	Layer1	Layer2	Layer3
		Category	Function	Value
Display self-diagnosis memory(※)	Display History 1 ( Latest(newest) of last Five)	7J	t0	01
	Display History 2			02
	Display History 3			03
	Display History 4			04
	Display History 5			05

### <HOW TO REMOVE ERROR CODE >

1. Press three key ( [On Timer] + [Fan Speed] + [Reset] ) button on the remote control for 5 seconds to avoid access by User.

2. Press “” (Temperature) button of the remote control and select the “7J” option.

3. Press “” (Fan Speed) button of the remote control, then Press “” (Temperature) button select the “t2” option.

4. Press “” (Fan Speed) button of the remote control, then Press “” (Temperature) button select the “01” option.

5. Press “” (On/Off) button of the remote control, and the error code will be removed.

	TIMER LAMP BLINKING	LD301 BLINKING	CODE	MEANING
INDOOR	-	-	000 00	Normal
	1 time		001 00	Refrigerant cycle fault
	2 times	-	-	Outdoor unit is under forced operation
	3 times	9 times	003 00	Communication error (indoor)
	9 times	-	009 00	Indoor thermistor defective
	10 times	-	010 00	Abnormal rotating numbers of DC fan motor
	12 times	9 times	012 00	Communication error (outdoor)
	13 times	-	013 00	EEPROM data reading error
	21 times	-	021 00	Interface defective (other machine cause)

< Cautions >

This function is effective only once immediately after the power is turned on. It will not work if you have performed another remote control operation beforehand. Note also that it may not function in response to a procedure other than the above. (If it does not work, turn off the power, turn it back on and repeat the procedure.)

If the memory stores nothing, performing a redisplay operation will not blink the lamp.

For a normal operation, turn off the power and turn it back on. After the above operation, the product will not receive a remote control signal normally.

After clearing the troubleshooting data, turn off the power. (If you do not turn off the power, the product will become unresponsive to remote control signals.)

## Forced cooling operation (Only single connection)

The cooling operation can be forcibly performed for collecting refrigerant and inspecting failures. Do not perform the forced cooling operation continuously for long hours, because the compressor continues to be in operational status, regardless of room temperature.


<How to start the operation>

- The operation of the unit should be stopped.
- Press and hold the "Temporary operation SW" shown in the right figure for 5 sec.

<How to stop the operation>

- Press and hold the "Temporary operation SW" again. Or stop the operation using the remote controller.

※During the forced cooling operation, the "Timer indicator" blinks twice.




Temporary operation switch

When performing the forced cooling operation, turn the power off once. If you press and hold the switch for 5 sec or longer, the forced cooling operation starts. To stop the forced cooling operation, press the switch once again or stop the operation using the remote controller.

## How to set up from Service setting mode


The Service function, which was set by DIP-SW setting or double pressing of the HHRC in the current model. it will be done by HHRC in GRAC as shown as below.

[On timer] + [Fan speed] + [Reset]  
( Press three Key for 5 seconds to avoid access by User )



※ If you don't do anything for 30 seconds, you will be out of the service setting mode.

## How to operate the HHRC method




Temp $\Delta$  $\nabla$  : Selection (in the same layer)  
 Mode : move to previous layer  
 Fan Speed : Move to next layer  
 ON/OFF : Decision/Send (at layer 3)  
 : Current setting check(at layer 2)  
 Filter: category initialization(at layer 1)  
 Filter + ON/OFF: all category initialization(at layer 1)  
 ※ To exit from this setting mode, you need to either not operate the HHRC panel for 30 seconds or press and hold the UP/Down key for 5 seconds.

Layer 1  
(category selection)

Layer 2  
(Function selection)

Layer 3  
(Setting select)



## Service setting item used for GRAC Entry

Category	Function Name	Value	HHRC LCD display			L1 (Category)						
			Layer1	Layer2	Layer3							
			Category	Function	Value							
Installation	Card Key	Disable	1A	A0	01	1A Installation						
		Card Key Input -A Enable			02							
		Card Key Input -B Enable			03							
		reserve			04-99							
	Mode Lock	Normal Mode	1A	A1	01	4E Fan control						
		Cooling Lock (Cool, Dry, Fan mode available)			02							
		Heating Lock (Heat and Fan mode available)			03							
		reserve			04-99							
	Auto restart	auto restart changeover disable	1A	A2	01	5F supporting service						
		auto restart by previous mode			02							
		reserve			03-99							
Cycle operation	Defrost selection Function	average area setting	3d	E0	01	L1 (Category)						
		cold area setting			02							
		reserve			03-99							
	Shift value adjustment of setting temperature (Cool Mode, Heat Mode)		(-5° C/-10° F)	3d	E1(Cool)/E2(Heat)	01	2C Clean					
			(-4° C/-8° F)			02						
			(-3° C/-6° F)			03						
			(-2° C/-4° F)			04						
			(-1° C/-2° F)			05						
			(±0° C/±0° F)			06						
			(+1° C/2° F)			07						
			(+2° C/4° F)			08						
			(+3° C/6° F)			09						
			(+4° C/8° F)			10						
			(+5° C/10° F)			11						
			reserve			12-99						
			Cycle operation			IDU fan control at cooling thermo-off		ultra low	3d	E3	01	L1 (Category)
								set fan speed			02	
reserve	03-99											
HHRC	Temperature Resolution change - 0.5 --> 1	0.5° C	6H	P0	01	1A Installation						
		1° C			02							
	Fan Speed key sequence	Auto-Silent - Low-Med-Hi-Super Hi		P1	01	2C Clean						
		Super Hi-Hi-Med-Lo-Silent -Auto			02							
	Operation Mode : Auto	Disable Selection on HHRC		P2	01	3d cycle operation adjustment						
		Enable Selection on HHRC			02							
	Operation Mode : Cool	Disable Selection on HHRC		P3	01	4E Fan control						
		Enable Selection on HHRC			02							
	Operation Mode : Dry	Disable Selection on HHRC		P4	01	5F supporting service						
		Enable Selection on HHRC			02							
	Operation Mode : Fan	Disable Selection on HHRC		P5	01	6H HHRC						
		Enable Selection on HHRC			02							

## Service setting item used for GRAC Entry

Category	Function Name	Value	HHRC LCD display			L1 (Category)
			Layer1	Layer2	Layer3	1A Installation
			Category	Function	Value	2C Clean
HHRC	Operation Mode : Heat	Disable Selection on HHRC	6H	P6	01	3d cycle operation adjustment
		Enable Selection on HHRC			02	4E Fan control
	Auto Fan speed : Enable / Disable	Disable Selection on HHRC		P8	01	5F supporting service
		Enable Selection on HHRC			02	6H HHRC
	Super hi Fan speed : Enable / Disable	Enable Selection on HHRC		P9	01	7J Diagnosis
		Disable Selection on HHRC			02	8L Future
HHRC	Cooling Lower limit setting	16 ° C	6H	PC	01	L1 (Category)
		17 ° C			02	1A Installation
		18 ° C			03	2C Clean
		19 ° C			04	3d cycle operation adjustment
		20 ° C			05	4E Fan control
		21 ° C			06	5F supporting service
		22 ° C			07	6H HHRC
		23 ° C			08	7J Diagnosis
		24 ° C			09	8L Future
		25 ° C			10	
		26 ° C			11	
		27 ° C			12	
		28 ° C			13	
		29 ° C			14	
		30 ° C			15	
		31 ° C			16	
		32 ° C			17	
HHRC	Heating Upper limit setting	32 ° C	6H	Pd	01	L1 (Category)
		31 ° C			02	1A Installation
		30 ° C			03	2C Clean
		29 ° C			04	3d cycle operation adjustment
		28 ° C			05	4E Fan control
		27 ° C			06	5F supporting service
		26 ° C			07	6H HHRC
		25 ° C			08	7J Diagnosis
		24 ° C			09	8L Future
		23 ° C			10	
		22 ° C			11	
		21 ° C			12	
		20 ° C			13	
		19 ° C			14	
		18 ° C			15	
		17 ° C			16	
		16 ° C			17	
Diagnosis	Display self-diagnosis memory(※)	Display History 1 ( Latest(newest) of last Five)	7J	t0	01	L1 (Category)
		Display History 2			02	1A Installation
		Display History 3			03	2C Clean
		Display History 4			04	3d cycle operation adjustment
		Display History 5			05	4E Fan control
	reserve	06-99				
	Display ODU self-check result	request		t1	01	5F supporting service
		reserve			02-99	
	Erase self-diagnosis memory(※)	request		t2	01	6H HHRC
		reserve			02-99	
	Humidity sensor failure diagnosis	request		t3	01	7J Diagnosis
		reserve			02-99	

## Buzzer sounding for showing error contents

**【Purpose】**


Reduction of "mis-communication about error contents" at contacting the service call center. **【Function】**

Add buzzer sounding for showing error contents during error, in addition to IDU LED action . **【How to use】**


When IDU or ODU has failed, and the Timer lamp is blinking. Service engineer can know error contents from the buzzer through phone.

**[Up/Down]**

( Press this Key for 5 seconds)




<IDU error example: timer LED will blink 3 times(interface defective(IDU) >



After "Short 2times x 1 beep", "3 times beep" will be repeated.

<ODU error example: operation LED will blink 2 times(peak current cut) >




After "Short 2times x 2 beep", "2 times beep" will be repeated.

## OTHER SETTING


### ▪ ID SELECTION

1. Press “Up/Down swing button” and “set. Temp. up button” and “reset button”, and release “reset button”.
2. Select from A or B by pressing “set.temp. button”.
3. Press “On/Off button” toward IDU.  
(EEPROM in HHRC will keep the A or B information.)




### ▪ DISPLAY MODE

1. Press “On Timer button” and “On/Off button” and “reset button”, and release “reset button”.
2. Fan speed icon(  ) on LCD will blink.
3. Press “On/Off button” toward IDU.



## Diagnosis and troubleshooting of indoor electric parts

### Initiating troubleshooting



### < Troubleshooting by using the self-diagnosis memory function >

- By using the self-diagnosis memory function, you can check the failure mode (※1) occurring in the outdoor electrical parts on the indoor unit side.

- Steps
1. Clear the troubleshooting data.
  2. Run the product for several minutes under the conditions where the compressor runs.
  3. Redisplay and check the data written in the self-diagnosis memory.

- The self-diagnosis memory function can also be used to catch sporadic failure phenomena.

- Steps
1. Clear the troubleshooting data.
  2. Have the user use the product as usual until a failure phenomenon occurs.  
(The period depends on the incidence of the phenomenon.)
  3. At a later date, redisplay and check the data written in the self-diagnosis memory.


- For the outdoor self-diagnosis display (OH thermistor heat-up, overload lower limit cut) stemming from the freezing cycle or operating condition, the time lag is long from operation startup to the emergence of the phenomenon. Moreover, it is affected by the temperature, sunshine, operating hours, and other factors of the day, so that the phenomenon may not be able to be identified at the time of a repair service visit. In that case too, use the self-diagnosis memory function (※2).
- The outdoor self-diagnosis display "overload lower limit cut" and "OH thermistor heat-up" can be identified only when you are using the self-diagnosis lamp of the outdoor unit and the self-diagnosis memory function of the indoor unit. Note that this will not be automatically displayed on the indoor unit side.

## Checking the indoor unit electrical parts

### Introduction

First check the failure phenomenon and status, and then move on to elaborate diagnosis.

#### Initiating troubleshooting



Turn off the power, wait at least 5 seconds, turn it back on, and observe the way the horizontal vanes move for about 30 seconds.

Check 1: Have the horizontal vanes moved? (Yes/No)

Set the remote control unit to cooling mode, temperature setting 16°C (summer), heating mode, temperature setting 32°C (winter) and operate the product.

Check 2: Has the product received the remote control signal and has the "operation lamp" gone on? (Yes/No)

If you responded "Yes" to Check 2:

Check 3: Is the compressor of the outdoor unit running? (Yes/No)

If you responded "No" to Check 2:

Check 4: Does the "emergency operation switch" work? (Yes/No)

#### Check results and next check items

Check 1	Check 2	Check 3	Check 4	Next check item
No	No	—	No	Go on to "The power will not become turned on".
Yes	No	—	Yes	Go on to "The product will not receive the remote control signal".
Yes	Yes	No	—	Go on to "The compressor will not run".

# 1. Failure phenomenon: The power will not become turned on.

[ Situation ] Neither initialization, remote control, nor any other step works on the vane position at power-on.

- [ Estimated failure locations ]
- 3.15 A fuse blown out
  - Control power circuit
  - Connector loose, wire break


Estimated cause of fuse blowout

- Abnormally high voltage applied to the power supply
- Indoor fan motor out of order
- Power circuit out of order

- [ Cautions ]
- Before work, check the power supply voltage. An abnormal voltage may be being supplied in some rare occasions due to a defect in the indoor wiring (a wire break in the neutral wire of the single-phase 3-wire power supply).
  - If the 3.15 A fuse has blown out, eliminate the cause of the fuse blowout. Otherwise, there will occur another fuse blowout.
  - If the 3.15 A fuse has blown out due to an abnormally high voltage to the power supply, the varistor (VA001) will deteriorate and become destroyed as well.
  - On a repair service visit due to the failure phenomenon of "The power will not become turned on", take a "3.15 A fuse" and a "varistor" with you.

## [ Diagnosis flow ]

### Initiating troubleshooting



## 2.Failure phenomenon: The product will not receive a remote control signal.

[Situation ] The product does not receive a remote control signal. It is not very responsive.

(The product does run normally in response to the emergency operation switch.)

[Estimated failure locations ]


- Remote control failure, remote control low battery level, remote control poorly set
- Remote control light-receiving unit
- Connector loose, wire break
- Normal product (external factors: the remote control units for lighting equipment and other equipment, electrical noise, etc.)

[Cautions ]

- Even if the product is trouble-free, a factor coming from outside the product may hamper the reception of signals from the remote control unit.
- Batteries may decline in capacity at low temperatures. Old batteries decline particularly much in voltage in the morning and evening of winter, resulting in the poor arrival of remote control signals. Instruct your users to use new alkaline batteries.

[Diagnosis flow ]

Initiating troubleshooting



[Cautions in replacing the indicating P.W.B] Be sure to replace the indicating P.W.B. components.

## How to identify sources of jamming in the reception of remote control signals

[ Situation ] The product may become poorly responsive to remote control signals due to external factors even though the product itself is trouble-free.



[ Estimating sources of jamming ] Identify the installation status of the air-conditioner and the indoor and outdoor environments to identify possible causes of the jamming.


- Indoor lighting equipment (quantity, type, location)
- Remote control units of other electrical products and equipment
- Is the grounding for the air-conditioner shared with other equipment?
- Are the surroundings of the air-conditioner clear of wireless antenna?
- Is the remote control light-receiving unit protected from direct sunlight?

[ Checking and actions ]

<p>Effects of lighting equipment (fluorescent lamps)</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Turn on and off the lighting equipment and check for its effects on the reception of remote control signals.</li> <li>· When cold, the fluorescent lamp tends to emit infrared rays with wavelengths close to those used in remote control.</li> </ul> <p>If you cannot detect the phenomenon about which your user is complaining at the time of your visit, such as "the product sometimes fails to receive remote control signals" and "the product fails to receive remote control signals in the morning alone", then turn off the lighting for about 20-30 minutes and wait for the fluorescent lamps to cool down before conducting another check.</p> <p>There are even cases where the product fails to receive remote control signals for 1 to 2 minutes only after the lighting equipment is turned on.</p> <ul style="list-style-type: none"> <li>· The noise status may vary with the dimming of the lighting equipment. In the case of lighting equipment with a dimmer, therefore, conduct a check with all the light intensities.</li> <li>· If the lighting equipment is the source of the jamming, the remote control light-receiving unit output usually shows a noise waveform as shown in the right-hand figure. In the case of slight jamming, this kind of waveform will not cause practical problems. However, intense degrees of jamming will disable the reception of remote control signals.</li> <li>· When the fluorescent lamp is old and is flickering, it may cause disorders in the reception of remote control signals.</li> </ul> <p><u>Actions proposed</u></p> <ol style="list-style-type: none"> <li>1. Make it hard for light of the lighting equipment to enter the remote control light-receiving unit. <ul style="list-style-type: none"> <li>· Separate the lighting equipment from the indoor unit.</li> <li>· Raise the lighting equipment.</li> <li>· Cover the upper half of the light-receiving panel from its rear side with aluminum tape or black vinyl tape.</li> </ul> <p>( This will also affect the reception of remote control signals. Therefore, set the range to be covered with tape to a range that is problem-free in practice, while checking the reception status.)</p> </li> <li>2. Add an interference filter to the front panel of the remote control light-receiving unit. <ul style="list-style-type: none"> <li>※ Lighting equipment that produces strong jamming exists although rarely.</li> <li>Some problems may therefore be unsolvable by managing the air-conditioner side alone.</li> </ul> </li> </ol>
<p>Effects of the remote control units of other equipment</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· If, on the remote control unit of a TV or audio equipment, its sound volume key or something similar is left pressed, infrared signals become continuously sent, thereby jamming the reception of remote control signals.</li> <li>· Check how the remote control unit and related components are stored, thereby checking if there is any possibility that a button may be inadvertently left pressed on the remote control unit of other equipment.</li> </ul> <p><u>Actions proposed</u></p> <p>If there is any such possibility, give explanations to your users to that effect and instruct them to exercise caution.</p>

Output waveform of the remote control light-receiving unit





<p>Effects of other electrical products</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Check the effects of light and power noises coming from other electrical products.</li> <li>· Turn on and off the electrical products, turn off the power and turn on the power, and check their effects on the reception of remote control signals.</li> <li>· For products whose operating states change, check the effects of each state.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Change the location relationship between the air-conditioner and the target products.</li> <li>· Use a different wall outlet for the target products.</li> </ul>
<p>Sharing a grounding</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Check for effects of electrical noises coming into the air-conditioner through grounding wires.</li> <li>· Check if the grounding works is for the air-conditioner alone or shared with other equipment. If there is any equipment that shares it, turn on and off that equipment and detach and reattach the power plugs and examine their effects on the reception of remote control signals.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Establish an independent grounding for the air-conditioner.</li> </ul> 
<p>Effects of radio waves</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Using a wireless transmitter near the air-conditioner may affect the reception of remote control signals.</li> <li>· Have your users try sending signals with a wireless transmitter and examine their effects on the reception of remote control signals.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Add a ferrite core to the power cord and F cable.</li> <li>· Add a ferrite core to the internal wiring of the indoor unit.</li> <li>· Move the wireless antenna.</li> </ul>
<p>Effects of direct sunlight</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Direct sunlight and other intense light make the remote control light-receiving unit less sensitive.</li> <li>· Check for any time zone where the remote control light-receiving unit of the indoor unit is affected by direct sunlight depending on the location of the sun and mirror reflection.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Block the sunlight to protect against direct sunlight.</li> </ul>

### 3. Failure phenomenon: The compressor will not run.

[ Situation ] The compressor will not run (the same state as the thermometer turned off), the product receives remote control signals normally. The self-diagnosis lamp (LD301) of the outdoor unit blinks once or becomes turned off.

[ Estimated failure locations ] · Room temperature thermistor, heat exchanger thermistor  
· Microcomputer peripheral circuit

[ Diagnosis flow ]  
Initiating troubleshooting



#### 4. Failure phenomenon: The fan motor will not stop.


[Situation ] I have conducted the stop operation on the product by remote control, but the indoor fan motor will not stop.  
(It stopped about 10 minutes later.)

[Estimated failure locations ]

- Indoor fan motor
- Fan motor drive circuit

[Diagnosis flow ]

##### Initiating troubleshooting



## 5. Timer lamp blinking: blinking once

[Situation] The timer lamp blinks one time and the product will not operate.  
(This is not a sign of a breakdown.)

[Estimated failure locations] · Reversing valve defective.  
· The refrigerating cycle block gas leak.

## 6. Timer lamp blinking: blinking twice

[Situation] The product is giving a display to indicate that it is performing forcible cooling.  
(This is not a sign of a breakdown.)

## 7. Timer lamp blinking: blinking three times


[Situation] The timer lamp blinks three times and the product will not operate.

[Estimated failure locations] · Meltdown of the terminal board temperature fuse (the terminal board poorly inserted into the F cable)  
· Outdoor communication circuit out of order

[Cautions] · If a terminal board is replaced to counter the meltdown of the terminal board temperature fuse, ensure that the F cable to be inserted into the terminal board has the appropriate dimension for peeling the insulation sheathing and that the insertion region is unbent before inserting it into the terminal board securely.

[Diagnosis flow]

Initiating troubleshooting



## 8. Timer lamp blinking: blinking four times

[Situation] The timer lamp blinks four times and the product will not operate.

[Estimated failure locations] · Outdoor unit error.  
· Please confirm the times of the LD301 blinking, and then see the outdoor selfcheck table.

## 9. Timer lamp blinking: blinking 9 times


[Situation] The timer lamp blinks 9 times and the product will not run.

[Estimated failure location] • Loose connector, wire break, or short-circuit in the room temperature thermistor, heat exchanger thermistor.

[Cautions] • Starting the product by remote control will initiate failure detection.  
(Merely turning on the power will not activate the failure detection function.)

[Diagnosis flow]

Initiating troubleshooting




## 10. Timer lamp blinking: blinking 10 times

[Situation] The timer lamp blinks 10 times and the product will not run.

- [Estimated failure locations]
- Loose connector or wire break in the indoor fan motor
  - Indoor fan motor mechanically locked
  - Indoor fan motor
  - Indoor fan motor drive circuit

[Diagnosis flow]

Initiating troubleshooting



### 11. Timer lamp blinking: blinking 12 times


[Situation] The timer blinks 12 times and the product will not run.

- [Estimated failure locations]
- Erroneous connection in the indoor-outdoor connection line (F cable)
  - Wire break or poor insertion of the indoor-outdoor connection line (F cable)
  - Electrical parts in the outdoor unit (communication circuit, power circuit error)
  - Communication error due to noise in other home electronics
- ※This does not constitute a failure in the air-conditioner

[Cautions] • When lines 1 and 2 of F cable are erroneously connected (crossed), the product may not enter self-diagnosis display mode. If the self-diagnosis memory stores data about "timer lamp blinked 12 times", then, just in case, check if the F cable is not erroneously connected.

#### [Diagnosis flow]

Initiating troubleshooting



### 12. Timer lamp blinking: blinking 13 times

[Situation] The timer lamp blinks 13 times and the product will not run.

[Estimated failure location] • EEPROM, microcomputer

[Diagnosis flow]

Replace the "indoor control P.W.B".

### 13. Timer lamp blinking: blinking 21 times

[Situation] The timer lamp blinks 21 times and the product will not run.

[Estimated failure location] • other machine cause


[Diagnosis flow]

Check "interference sources".

# PARTS LIST AND DIAGRAM

## INDOOR UNIT

MODEL : RAK-VJ60PHAE  
RAK-VJ70PHAE



MODEL RAK-VJ60PHAE

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	PMK-VJ60PHAE R11	1	TANGENTIAL FAN
2	PMK-DJ10PCASV R10	1	P-BEARING ASSY
3	REFER TO JCH-WH RAK-VJ18/25/35/50PHAE SERIES RELATED PART #	1	REMOTE CONTROL
4	REFER TO JCH-WH RAK-VJ18/25/35/50PHAE SERIES RELATED PART #	1	REMOTE CONTROL HOLDER
5	PMK-VJ60PHAE R04	1	DRAINPAN ASSY
6	PMK-VJ60PHAE R05	1	FRONT COVER ASSY
7	PMK-VJ60PHAE R06	1	FRONT PANEL
8	PMK-DJ10PCASV R17	1	S-COVER-L
9	PMK-DJ10PCASV R18	1	S-COVER-R
10	PMK-DJ10PCASV R07	1	AUTO SWEEP MOTOR
11	PMK-VJ60PHAE R07	1	CABINET
12	PPMK-DJ60PHAE R05	1	BEARING COVER
13	PMK-VJ60PHAE R08	1	FM-BASE-L
14	PMK-DJ10PCASV R22	1	FM-BASE-R
15	PMK-DJ18PCASV R10	1	MOUNTING PLATE
16	PMK-DJ10PCASV R16	1	PIPE SUPPORT
17	PMK-VJ60PHAE R09	1	AIR FILTER
18	PMK-VJ60PHAE R10	1	CYCLE ASSY
19	PMK-VJ60PHAE R16	1	H-DEFLECTOR
20	REFER TO JCH-WH RAK-VJ18/25/35/50PHAE SERIES RELATED PART #	1	WIFI ASSEMBLY
21	PMK-VJ60PHAE R03	1	PWB-MAIN
22	PMK-DJ10PCASV R02	1	PWB RECEIVER
23	PMK-DJ10PCASV R19	1	THERMISTOR
24	SPX-CFH22VR	1	ACL FILTER
25	PMK-DJ60PHAE R04	1	SENSOR ASSEMBLY
26	PMK-VJ60PHAE R12	1	MOTION SENSOR ASSY
27	PMK-VJ60PHAE R13	1	IONIZER ASSY
28	PMK-VJ60PHAE R14	1	AUTO SWEEP MOTOR (VR)
29	PMK-VJ60PHAE R15	1	AUTO SWEEP MOTOR (VL)
30	PMK-VJ60PHAE R02	1	FAN MOTOR

MODEL RAK-VJ70PHAE

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	PMK-VJ60PHAE R11	1	TANGENTIAL FAN
2	PMK-DJ10PCASV R10	1	P-BEARING ASSY
3	REFER TO JCH-WH RAK-VJ18/25/35/50PHAE SERIES RELATED PART #	1	REMOTE CONTROL
4	REFER TO JCH-WH RAK-VJ18/25/35/50PHAE SERIES RELATED PART #	1	REMOTE CONTROL HOLDER
5	PMK-VJ60PHAE R04	1	DRAINPAN ASSY
6	PMK-VJ60PHAE R05	1	FRONT COVER ASSY
7	PMK-VJ60PHAE R06	1	FRONT PANEL
8	PMK-DJ10PCASV R17	1	S-COVER-L
9	PMK-DJ10PCASV R18	1	S-COVER-R
10	PMK-DJ10PCASV R07	1	AUTO SWEEP MOTOR
11	PMK-VJ60PHAE R07	1	CABINET
12	PPMK-DJ60PHAE R05	1	BEARING COVER
13	PMK-VJ60PHAE R08	1	FM-BASE-L
14	PMK-DJ10PCASV R22	1	FM-BASE-R
15	PMK-DJ18PCASV R10	1	MOUNTING PLATE
16	PMK-DJ10PCASV R16	1	PIPE SUPPORT
17	PMK-VJ60PHAE R09	1	AIR FILTER
18	PMK-VJ70PHAE R02	1	CYCLE ASSY
19	PMK-VJ60PHAE R16	1	H-DEFLECTOR
20	REFER TO JCH-WH RAK-VJ18/25/35/50PHAE SERIES RELATED PART #	1	WIFI ASSEMBLY
21	PMK-VJ70PHAE R01	1	PWB-MAIN
22	PMK-DJ10PCASV R02	1	PWB RECEIVER
23	PMK-DJ10PCASV R19	1	THERMISTOR
24	SPX-CFH22VR	1	ACL FILTER
25	PMK-DJ60PHAE R04	1	SENSOR ASSEMBLY
26	PMK-VJ60PHAE R12	1	MOTION SENSOR ASSY
27	PMK-VJ60PHAE R13	1	IONIZER ASSY
28	PMK-VJ60PHAE R14	1	AUTO SWEEP MOTOR (VR)
29	PMK-VJ60PHAE R15	1	AUTO SWEEP MOTOR (VL)
30	PMK-VJ60PHAE R02	1	FAN MOTOR

# HITACHI

**RAK-VJ60PHAE  
RAK-VJ70PHAE**

**PM NO. 0803E**

Printed in Malaysia

**SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT**

---

**ROOM AIR CONDITIONER**  
INDOOR UNIT

---

**MARCH 2023 Refrigeration & Air-Conditioning Division**